




Service Manual

Air Conditioner



Indoor Unit
CS-Z25CD3EAW
CS-Z35CD3EAW
CS-Z50CD3EAW
CS-Z60CD3EAW

Outdoor Unit
CU-Z25CBEA
CU-Z35CBEA
CU-Z50CBEA
CU-Z60CBEA

Destination
Europe
CIS
Asia

Please file and use this manual together with the service manual for Model No. CU-2Z35CBE, CU-2Z41CBE, CU-2Z50CBE, CU-3Z52CBE, CU-3Z68CBE, CU-4Z68CBE, CU-4Z80CBE, CU-5Z90CBE, CU-4WZ90CBE5, Order No. PAPAMY2512057CE, PAPAMY2603058CE.

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

CAUTION

R32 REFRIGERANT – This Air Conditioner contains and operates with refrigerant R32.

THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL.

Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of this product.

TABLE OF CONTENTS

	PAGE		PAGE
1. Safety Precautions	3	14.1 Basic Function	76
2. Precaution for Using R32 Refrigerant	5	14.2 Quiet Operation (Cooling)	79
3. Specifications	9	14.3 Quiet Operation (Heating)	79
4. Features	17	14.4 Powerful Operation	79
5. Location of Controls and Components	18	14.5 Weekly Timer	80
5.1 Indoor Unit	18	14.6 Auto Restart Control	80
5.2 Outdoor Unit	18	14.7 HA Terminal (HAJEM-A)	81
5.3 Remote Control	19	14.8 Drain Pump Control	82
6. Dimensions	22	14.9 Pump down Operation by CN-S	82
6.1 Indoor Unit	22	15. Operation Control (For Multi Split Connection)	83
6.2 Outdoor Unit	23	15.1 Cooling operation	83
7. Refrigeration Cycle Diagram	25	15.2 Soft Dry Operation	83
7.1 CS-Z25CD3EAW CU-Z25CBEA	25	15.3 Heating Operation	83
7.2 CS-Z35CD3EAW CU-Z35CBEA	25	15.4 Automatic Operation	84
CS-Z50CD3EAW CU-Z50CBEA	26	15.5 Indoor Fan Motor Operation	84
CS-Z60CD3EAW CU-Z60CBEA	26	15.6 Powerful Mode Operation	84
8. Block Diagram	27	15.7 Auto Restart Control	84
8.1 CS-Z25CD3EAW CU-Z25CBEA	27	16. Protection Control	85
8.2 CS-Z35CD3EAW CU-Z35CBEA	27	16.1 Protection Control for All Operations	85
CS-Z50CD3EAW CU-Z50CBEA	28	16.2 Protection Control for Cooling & Soft Dry Operation	87
CS-Z60CD3EAW CU-Z60CBEA	28	16.3 Protection Control for Heating Operation	88
9. Wiring Connection Diagram	29	17. Servicing Mode	90
9.1 Indoor Unit	29	17.1 TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)	90
9.2 Outdoor Unit	30	18. Troubleshooting Guide	92
10. Electronic Circuit Diagram	32	18.1 Refrigeration Cycle System	92
10.1 Indoor Unit	32	18.2 Breakdown Self Diagnosis Function	94
10.2 Outdoor Unit	33	18.3 Error Codes Table	95
11. Printed Circuit Board	35	18.4 Troubleshooting Flowchart	97
11.1 Indoor Unit	35	19. Disassembly and Assembly Instructions ...	131
11.2 Outdoor Unit	36	19.1 Indoor Electronic Controller, Blower Fan, Fan Motor & Drain Motor Removal Procedure	131
12. Installation Instruction	38	19.2 Outdoor Electronic Controller Removal Procedure	135
12.1 Indoor Unit	39	20. Technical Data	138
12.2 Outdoor Unit	51	20.1 Cool Mode Performance Data	138
13. Installation and Servicing Air Conditioner using R32	56	20.2 Heat Mode Performance Data	140
13.1 About R32 Refrigerant	56	20.3 Fan Performance	141
13.2 Characteristics of R32 Refrigerant	56	21. Service Data	145
13.3 Refrigerant piping installation • Tools used in services	58	21.1 Cool Mode Outdoor Air Temperature Characteristic	145
13.4 New installation, Relocation, Repairing of Refrigerant Cycle System The Procedures	62	21.2 Heat Mode Outdoor Air Temperature Characteristic	149
13.5 Piping installation of R32	63	21.3 Piping Length Correction Factor	153
13.6 Installation, Relocation, and Service	64	22. Exploded View and Replacement Parts List	156
13.7 Repairing of refrigerant cycle / Brazing point	68	22.1 Indoor Unit	156
13.8 <Reference> Analysis method for no error code, no cooling / no warming	74	22.2 Outdoor Unit	161
14. Operation and Control	76		

• Specifications, designs and contents in this Service Manual are subject to change without notice.

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation.
- Electrical work must be installed by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

 WARNING	This indication shows the possibility of causing death or serious injury.
 CAUTION	This indication shows the possibility of causing injury or damage to properties only.

The items to be followed are classified by symbols:		Symbol with white background denotes item that is PROHIBITED.
		Symbol with dark background denotes item that must be carried out.

- Carry out test running to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

 WARNING	
	• Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury. • Do not install outdoor unit near handrail of veranda. When installing air-conditioner unit on veranda of a high rise building, child may climb up to outdoor unit and cross over the handrail causing an accident. • Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire. • Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen. • Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury. • Do not sit or step on the unit, you may fall down accidentally. • Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing. • When installing or relocating air conditioner, do not let any substance other than the specified refrigerant, eg. air etc mix into refrigeration cycle (piping). Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc. • Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death. • Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc. • Do not use joint cable for indoor/ outdoor connection cable. Use the specified indoor/outdoor connection cable, refer to instruction 12.2.5 CONNECT THE CABLE TO THE OUTDOOR UNIT and connect tightly for indoor/outdoor connection. Clamp the cable so that no external force will have impact on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.
	• For R32/R410A model, use piping, flare nut and tools which is specified for R32/R410A refrigerant. Using of existing (R22) piping, flare nut and tools may cause abnormally high pressure in the refrigerant cycle (piping), and possibly result in explosion and injury. For R32 and R410A, the same flare nut on the outdoor unit side and pipe can be used. • Since the working pressure for R32/R410A is higher than that of refrigerant R22 model, replacing conventional piping and flare nuts on the outdoor unit side are recommended. • If reuse piping is unavoidable, refer to instruction "IN CASE OF REUSING EXISTING REFRIGERANT PIPING" • Thickness of copper pipes used with R32/R410A must be more than 0.8 mm (3/4 - 2.25HP). Never use copper pipes thinner than 0.8 mm (3/4 - 2.25HP). • It is desirable that the amount of residual oil less than 40 mg/10 m. • Engage authorized dealer or specialist for installation. • If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire. • For refrigeration system work, install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire. • Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock. • Install at a strong and firm location which is able to withstand weight of the set. If the strength is not enough or installation is not properly done, the set will drop and cause injury. • For electrical work, follow the national regulation, legislation and this installation instructions. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it will cause electrical shock or fire. • Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause fire or electrical shock. • This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD), with sensitivity of 30 mA at 0.1 sec or less. Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown.

 WARNING

	- During installation, install the refrigerant piping properly before running the compressor. Operation of compressor without fixing refrigeration piping and valves at opened position will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc. - During pump down operation, stop the compressor before removing the refrigeration piping. Removal of refrigeration piping while compressor is operating and valves are opened will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc. - Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage. - After completion of installation, confirm there is no leakage of refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire. - Ventilate if there is refrigerant gas leakage during operation. It may cause toxic gas when the refrigerant contacts with fire. - Be aware that refrigerants might not contain an odour. - Do not modify the machine, part, material during repairing service. - If wiring unit is supplied as repairing part, do not repair or connect the wire even only partial wire break. Exchange the whole wiring unit. - Do not wrench the fasten terminal. Pull it out or insert it straightly. - Must not use other parts except original parts describe in catalog and manual.
	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.

 CAUTION

	- Handle the unit surface with care to avoid scratching the surface by sharp or rough items (e.g. fingernails, tools, rings, etc). Wear hand gloves when performing installation work. - Do not install the unit in a place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire. - Prevent liquid or vapor from entering sumps or sewers since vapor is heavier than air and may form suffocating atmospheres. - Do not release refrigerant during piping work for installation, re-installation and during repairing refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite. - Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc. - Do not touch the sharp aluminium fin, sharp parts may cause injury.
	- Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture. - Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this air conditioner may increase the risk of rupture and this may result in loss damage or injury and/or property. Power supply connection to the room air conditioner. Use power supply cord 3 × 1.5 mm² (3/4 ~ 1.5HP), 3 × 2.5 mm² (2.0 ~ 2.25HP) type designation 60245 IEC 57 or heavier cord. Connect the power supply cord of the air conditioner to the mains using one of the following method. Power supply point should be in easily accessible place for power disconnection in case of emergency. - In some countries, permanent connection of this air conditioner to the power supply is prohibited. - Power supply connection to the receptacle using power plug. Use an approved 15/16 A (3/4 ~ 1.5HP), 16 A (2.0 ~ 2.25HP) power plug with earth pin for the connection to the socket. - Power supply connection to a circuit breaker for the permanent connection. Use an approved 16 A (3/4 ~ 2.25HP) circuit breaker for the permanent connection. It must be a double pole switch with a minimum 3.0 mm contact gap. - Installation work. It may need two people to carry out the installation work. - Keep any required ventilation openings clear of obstruction. - Pb free solder has a higher melting point than standard solder; typically the melting point is 50°F – 70°F (30°C – 40°C) higher. Please use a high temperature solder iron. In case of the soldering iron with temperature control, please set it to 700 ± 20°F (370 ± 10°C). Pb free solder will tend to splash when heated too high (about 1100°F / 600°C). - Do not touch the sharp aluminum fins or edges of metal parts. If you are required to handle sharp parts during installation or servicing, please wear hand glove. Sharp parts may cause injury. - Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage. - Do not touch outdoor unit air inlet and aluminium fin. It may cause injury.

2. Precaution for Using R32 Refrigerant

- Pay careful attention to the following precaution points and the installation work procedures.

 WARNING	
	• When connecting flare at indoor side, make sure that the flare connection is used only once, if torqued up and released, the flare must be remade. Once the flare connection was torqued up correctly and leak test was made, thoroughly clean and dry the surface to remove oil, dirt and grease by following instructions of silicone sealant. Apply neutral cure (Alkoxy type) & ammonia-free silicone sealant that is non-corrosive to copper & brass to the external of the flared connection to prevent the ingress of moisture on both the gas & liquid sides. (Moisture may cause freezing and premature failure of the connection). • The appliance shall be stored, installed and operated in a well ventilated room with indoor floor area larger than A_{min} (m²) [refer Table A] and without any continuously operating ignition source. Keep away from open flames, any operating gas appliances or any operating electric heater. Else, it may explode and cause injury or death. • The mixing of different refrigerants within a system is prohibited. Models that use refrigerant R32 and R410A have a different charging port thread diameter to prevent erroneous charging with refrigerant R22 and for safety. Therefore, check beforehand. [The charging port thread diameter for R32 and R410A is 12.7 mm (1/2 inch).] • Ensure that foreign matter (oil, water, etc.) does not enter the piping. Also, when storing the piping, securely seal the opening by pinching, taping, etc. (Handling of R32 is similar to R410A.) • Operation, maintenance, repairing and refrigerant recovery should be carried out by trained and certified personnel in the use of flammable refrigerants and as recommended by the manufacturer. Any personnel conducting an operation, servicing or maintenance on a system or associated parts of the equipment should be trained and certified. • Any part of refrigerating circuit (evaporators, air coolers, AHU, condensers or liquid receivers) or piping should not be located in the proximity of heat sources, open flames, operating gas appliance or an operating electric heater. • The user/owner or their authorized representative shall regularly check the alarms, mechanical ventilation and detectors, at least once a year, where as required by national regulations, to ensure their correct functioning. • A logbook shall be maintained. The results of these checks shall be recorded in the logbook. • In case of ventilations in occupied spaces shall be checked to confirm no obstruction. • Before a new refrigerating system is put into service, the person responsible for placing the system in operation should ensure that trained and certified operating personnel are instructed on the basis of the instruction manual about the construction, supervision, operation and maintenance of the refrigerating system, as well as the safety measures to be observed, and the properties and handling of the refrigerant used. • The general requirement of trained and certified personnel are indicated as below: a) Knowledge of legislation, regulations and standards relating to flammable refrigerants; and, b) Detailed knowledge of and skills in handling flammable refrigerants, personal protective equipment, refrigerant leakage prevention, handling of cylinders, charging, leak detection, recovery and disposal; and, c) Able to understand and to apply in practice the requirements in the national legislation, regulations and Standards; and, d) Continuously undergo regular and further training to maintain this expertise. • Air-conditioner piping in the occupied space shall be installed in such a way to protect against accidental damage in operation and service. • Precautions shall be taken to avoid excessive vibration or pulsation to refrigerating piping. • Ensure protection devices, refrigerating piping and fittings are well protected against adverse environmental effects (such as the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris). • Expansion and contraction of long runs piping in refrigerating systems shall be designed and installed securely (mounted and guarded) to minimize the likelihood hydraulic shock damaging the system. • Protect the refrigerating system from accidental rupture due to moving furniture or reconstruction activities. • To ensure no leaking, field-made refrigerant joints indoors shall be tightness tested. The test method shall have a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure. No leak shall be detected.

 CAUTION

	1. General • Must ensure the installation of pipe-work shall be kept to a minimum. Avoid use dented pipe and do not allow acute bending. • Must ensure pipe-work shall be securely mounted and guarded from physical damage. • Must comply with national gas regulations, state municipal rules and legislation. Notify relevant authorities in accordance with all applicable regulations. • Must ensure mechanical connections be accessible for maintenance purposes. • In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction. • When disposal of the product, do follow to the precautions in #10 and comply with national regulations. • In case of field charge, the effect on refrigerant charge caused by the different pipe length has to be quantified, measured and labelled. Always contact to local municipal offices for proper handling. • The refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed. • Ensure refrigerant charge not to leak. • Wear appropriate protective equipment, including respiratory protection, as conditions warrant. • Keep all sources of ignition and hot metal surfaces away. • Electrical components that can arc or spark shall only be replaced with parts specified by the appliance manufacturer. Replacement with other parts may result in the ignition of refrigerant in the event of a leak.
	2. Servicing <u>2-1. Qualification of workers</u> • Any qualified person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification. • Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants. • Servicing shall be performed only as recommended by the manufacturer. • The system is inspected, regularly supervised and maintained by a trained and certified service personnel who is employed by the person user or party responsible.
	<u>2-2. Checks to the area</u> • Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised. For repair to the refrigerating system, the precautions in #2-3 to #2-7 must be followed before conducting work on the system.
	<u>2-3. Work procedure</u> • Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.
	<u>2-4. General work area</u> • All maintenance staff and others working in the local area shall be instructed and supervised on the nature of work being carried out. • Avoid working in confined spaces. Always ensure away from source, at least 2 meter of safety distance, or zoning of free space area of at least 2 meter in radius.
	<u>2-5. Checking for presence of refrigerant</u> • The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres. • Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non sparking, adequately sealed or intrinsically safe. • In case of leakage/spillage happened, immediately ventilate area and stay upwind and away from spill/release. • In case of leakage/spillage happened, do notify persons down wind of the leaking/spill, isolate immediate hazard area and keep unauthorized personnel out.
	<u>2-6. Presence of fire extinguisher</u> • If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available at hand. • Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
	<u>2-7. No ignition sources</u> • No person carrying out work in relation to a refrigerating system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it can lead to the risk of fire or explosion. He/She must not be smoking when carrying out such work. • All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space. • Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. • "No Smoking" signs shall be displayed.
	<u>2-8. Ventilated area</u> • Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. • A degree of ventilation shall continue during the period that the work is carried out. • The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

2-9. Checks to the refrigerating equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants.
 - The refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed.
 - The ventilation machinery and outlets are operating adequately and are not obstructed.
 - If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
 - Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.
 - Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which can corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are properly protected against being so corroded.

2-10. Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- Initial safety checks shall include but not limit to:-
 - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking.
 - That there is no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - That there is continuity of earth bonding.
- At all times the manufacturer's maintenance and service guidelines shall be followed.
- If in doubt consult the manufacturer's technical department for assistance.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- The owner of the equipment must be informed or reported so all parties are advised thereafter.

3. Sealed electrical components

- Sealed electrical components shall not be repaired.

4. Cabling

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
- The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

5. Detection of flammable refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.
- The following leak detection methods are deemed acceptable for all refrigerant systems.
 - No leaks shall be detected when using detection equipment with a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure for example, a universal sniffer.
 - Electronic leak detectors may be used to detect flammable refrigerants, but the sensitivity can be inadequate or can need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
 - Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
 - Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.
 - Leak detection fluids are also suitable for use with most refrigerants, for example, bubble method and fluorescent agent method. The use of detergents containing chlorine shall be avoided as the chlorine can react with the refrigerant and corrode the copper pipe-work.
 - If a leak is suspected, all naked flames shall be removed/extinguished.
 - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. The precautions in #6 must be followed to remove the refrigerant.

6. Refrigerant removal and circuit evacuation

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants, it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to:

- safely remove refrigerant following local and national regulations -> • evacuate -> • purge the circuit with inert gas -> • evacuate -> • continuously flush with inert gas when using flame to open circuit -> • open the circuit

- The refrigerant charge shall be recovered into the correct recovery cylinders.
- The system shall be purged with OFN to render the appliance safe. (remark: OFN = oxygen free nitrogen, type of inert gas)
- This process may need to be repeated several times.
- Compressed air or oxygen shall not be used for this task.
- Purging of the refrigerant circuit shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
- This process shall be repeated until no refrigerant is within the system.
- The system shall be vented down to atmospheric pressure to enable work to take place.
- Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and there is ventilation available.

7. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed.
 - Ensure that contamination of different refrigerants does not occur when using charging equipment.
 - Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - Cylinders shall be kept in an appropriate position according to the instructions.
 - Ensure that the refrigerating system is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already labelled).
 - Extreme care shall be taken not to overfill the refrigerating system.
- Prior to recharging the system it shall be pressure tested with OFN (refer to #6).
- The system shall be leak tested on completion of charging but prior to commissioning.
- A follow up leak test shall be carried out prior to leaving the site.
- Electrostatic charge may accumulate and create a hazardous condition when charging and discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.

8. Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant.
- It is essential that electrical power is available before the task is commenced.
 - a) Become familiar with the equipment and its operation.
 - b) Isolate system electrically.
 - c) Before attempting the procedure ensure that:

- mechanical handling equipment is available, if required, for handling refrigerant cylinders;
- all personal protective equipment is available and being used correctly;
- the recovery process is supervised at all times by a competent person;
- recovery equipment and cylinders conform to the appropriate standards.

- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.
- Electrostatic charge may accumulate and create a hazardous condition when charging or discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.

9. Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.
- The label shall be dated and signed.
- Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

10. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is required to follow good practice so that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerants. Consult manufacturer if in doubt.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process.
- Draining of oil from a system shall be carried out safely.

3. Specifications

Model			Indoor	CS-Z25CD3EAW			CS-Z35CD3EAW		
			Outdoor	CU-Z25CBEA			CU-Z35CBEA		
Performance Test Condition				EUROVENT			EUROVENT		
Power Supply			Phase, Hz	Single, 50			Single, 50		
			V	230			230		
				Min.	Mid.	Max.	Min.	Mid.	Max.
Cooling	Capacity		kW	0.85	2.50	3.20	0.85	3.50	4.00
			BTU/h	2900	8530	10900	2900	11900	13600
			Kcal/h	730	2150	2750	730	3010	3440
	Running Current		A	-	2.70	-	-	4.10	-
	Input Power		W	240	580	850	240	910	1.19k
	Annual Consumption		kWh	-	290	-	-	455	-
	EER CLASS			-	A	-	-	A	-
	EER		W/W	3.54	4.31	3.76	3.54	3.85	3.36
			BTU/hW	12.08	14.71	12.82	12.08	13.08	11.43
			Kcal/hW	3.04	3.71	3.24	3.04	3.31	2.89
	ErP	Pdesign	kW	2.5			3.5		
		SEER	(W/W)	6.2			6.2		
		Annual Consumption	kWh	141			198		
		Class		A++			A++		
	Power Factor		%	-	93	-	-	97	-
	Indoor Noise (H / L / QLo)		dB(A)	33 / 27 / 24			33 / 27 / 24		
			Power Level dB(A)	52 / -			52 / -		
	Outdoor Noise (H / L)		dB(A)	46 / -			48 / -		
			Power Level dB(A)	61 / -			63 / -		
Heating	Capacity		kW	0.85	3.20	4.60	0.85	4.20	5.10
			BTU/h	2900	10900	15700	2900	14300	17400
			Kcal/h	730	2750	3960	730	3610	4390
	Running Current		A	-	3.60	-	-	4.90	-
	Input Power		W	230	800	1.25k	230	1.10k	1.42k
	COP CLASS			-	A	-	-	A	-
	COP		W/W	3.70	4.00	3.68	3.70	3.82	3.59
			BTU/hW	12.61	13.63	12.56	12.61	13.00	12.25
			Kcal/hW	3.17	3.44	3.17	3.17	3.28	3.09
	ErP	Pdesign	kW	2.6			2.8		
		Tbivalent	°C	-10			-10		
		SCOP	(W/W)	4.2			4.1		
		Annual Consumption	kWh	867			956		
		Class		A+			A+		
	Power Factor		%	-	97	-	-	98	-
	Indoor Noise (H / L / QLo)		dB(A)	35 / 27 / 24			35 / 27 / 24		
			Power Level dB(A)	54 / -			54 / -		
	Outdoor Noise (H / L)		dB(A)	47 / -			48 / -		
			Power Level dB(A)	62 / -			63 / -		
Low Temp. : Capacity (kW) / I.Power (W) / COP				3.33 / 1.11k / 3.00			3.70 / 1.26k / 2.94		
Extr Low Temp. : Capacity (kW) / I.Power (W) / COP				2.60 / 1.14k / 2.28			3.00 / 1.23k / 2.44		

Model				Indoor	CS-Z25CD3EAW		CS-Z35CD3EAW	
				Outdoor	CU-Z25CBEA		CU-Z35CBEA	
Max Current (A) / Max Input Power (W)					5.6 / 1.25k		6.6 / 1.42k	
Starting Current (A)					3.60		4.90	
Compressor	Type				Hermetic Motor (Rotary)		Hermetic Motor (Rotary)	
	Motor Type				Brushless (6 poles)		Brushless (6 poles)	
	Output Power			W	700		700	
Maximum High Pressure				MPa (bar)	5.0 (50.0)		5.0 (50.0)	
Design / Operating Pressure, PS				MPa (bar) H.P. / L.P.	4.15 (41.5) / 2.55 (25.5)		4.15 (41.5) / 2.55 (25.5)	
Indoor Fan	Type				SIROCCO		SIROCCO	
	Material				GFZ010A / GF20		GFZ010A / GF20	
	Motor Type				DC Motor (8-poles)		DC Motor (8-poles)	
	Input Power			W	-		-	
	Output Power			W	51		51	
	Speed	QLo	Cool	rpm	800		800	
			Heat	rpm	790		790	
		Lo	Cool	rpm	880		880	
			Heat	rpm	860		860	
		Me	Cool	rpm	990		1010	
			Heat	rpm	980		1000	
		Hi	Cool	rpm	1100		1140	
			Heat	rpm	1100		1140	
	SHi	Cool	rpm	1150		1190		
		Heat	rpm	1150		1190		
Outdoor Fan	Type				Propeller Fan		Propeller Fan	
	Material				PP		PP	
	Motor Type				DC Motor (8-poles)		DC Motor (8-poles)	
	Input Power			W	-		-	
	Output Power			W	40		40	
	Speed	Hi	Cool	rpm	820		850	
			Heat	rpm	780		790	
Moisture Removal				L/h (Pt/h)	1.5 (3.2)		2.0 (4.2)	
Indoor Airflow	QLo	Cool	m³/min (ft³/min.)	7.4 (261)		7.2 (254)		
		Heat	m³/min (ft³/min.)	7.3 (258)		7.1 (251)		
	Lo	Cool	m³/min (ft³/min.)	8.2 (290)		8.2 (290)		
		Heat	m³/min (ft³/min.)	8.0 (283)		7.9 (279)		
	Me	Cool	m³/min (ft³/min.)	9.3 (328)		9.5 (335)		
		Heat	m³/min (ft³/min.)	9.3 (328)		9.5 (335)		
	Hi	Cool	m³/min (ft³/min.)	10.5 (370)		11.2 (395)		
		Heat	m³/min (ft³/min.)	10.5 (370)		11.2 (395)		
	SHi	Cool	m³/min (ft³/min.)	11.1 (392)		11.7 (413)		
		Heat	m³/min (ft³/min.)	11.1 (392)		11.7 (413)		
Outdoor Airflow	Hi	Cool	m³/min (ft³/min.)	28.7 (1015)		34.3 (1210)		
		Heat	m³/min (ft³/min.)	27.2 (960)		31.8 (1125)		
Refrigeration Cycle	Control Device			Expansion Valve		Expansion Valve		
	Refrigerant Oil		cm³	FW50S (320)		FW50S (320)		
	Refrigerant Type		kg (oz)	R32, 0.88 (31.1)		R32, 0.97 (34.2)		
F-Gas	GWP			675		675		
	CO2eq (ton) (Precharged Amount / Maximum Charged Amount)			0.59 / 0.68		0.65 / 0.74		

Model		Indoor	CS-Z25CD3EAW		CS-Z35CD3EAW	
		Outdoor	CU-Z25CBEA		CU-Z35CBEA	
Dimension	Height (I/D / O/D)	mm (inch)	200 (7-7/8) / 542 (21-11/32)		200 (7-7/8) / 619 (24-3/8)	
	Width (I/D / O/D)	mm (inch)	750 (29-17/32) / 780 (30-23/32)		750 (29-17/32) / 824 (32-15/32)	
	Depth (I/D / O/D)	mm (inch)	640 (25-7/32) / 289 (11-13/32)		640 (25-7/32) / 299 (11-25/32)	
Weight	Net (I/D / O/D)	kg (lb)	19 (42) / 32 (71)		19 (42) / 33 (73)	
Piping	Pipe Diameter (Liquid / Gas)	mm (inch)	6.35 (1/4) / 9.52 (3/8)		6.35 (1/4) / 9.52 (3/8)	
	Standard length	m (ft)	5.0 (16.4)		5.0 (16.4)	
	Length range (min – max)	m (ft)	3 (9.8) ~ 20 (65.6)		3 (9.8) ~ 20 (65.6)	
	I/D & O/D Height different	m (ft)	15.0 (49.2)		15.0 (49.2)	
	Additional Gas Amount	g/m (oz/ft)	10 (0.1)		10 (0.1)	
	Length for Additional Gas	m (ft)	7.5 (24.6)		7.5 (24.6)	
Drain Hose	Inner Diameter	mm	16		16	
	Length	mm	117.5		117.5	
Indoor Heat Exchanger	Fin Material		Aluminium (Pre Coat)		Aluminium (Pre Coat)	
	Fin Type		Slit Fin		Slit Fin	
	Row × Stage × FPI		3 × 12 × 18		3 × 12 × 18	
	Size (W × H × L)	mm	590 × 282 × 38.1		590 × 282 × 38.1	
Outdoor Heat Exchanger	Fin Material		Aluminium		Aluminium	
	Fin Type		Corrugated Fin (Pre Coat)		Corrugated Fin (Pre Coat)	
	Row × Stage × FPI		2 × 24 × 19		2 × 28 × 17	
	Size (W × H × L)	mm	36.4 × 504 × 824.2:793.7		36.38 × 588 × 856.3:827.7	
Air Filter	Material		-		-	
	Type		-		-	
Power Supply			Outdoor		Outdoor	
Power Supply Cord		A	Nil		Nil	
Thermostat			Electronic Control		Electronic Control	
Protection Device			Electronic Control		Electronic Control	
			Dry Bulb	Wet Bulb	Dry Bulb	Wet Bulb
Indoor Operation Range	Cooling	Maximum °C	32	23	32	23
		Minimum °C	16	11	16	11
	Heating	Maximum °C	30	-	30	-
		Minimum °C	16	-	16	-
Outdoor Operation Range	Cooling	Maximum °C	43	26	43	26
		Minimum °C	-10	-	-10	-
	Heating	Maximum °C	24	18	24	18
		Minimum °C	-15	-16	-15	-16

1. Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and outdoor air temperature of 35°C Dry Bulb (95°F Dry Bulb), 24°C Wet Bulb (75.2°F Wet Bulb).
2. Heating capacities are based on indoor temperature of 20°C Dry Bulb (68°F Dry Bulb) and outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb).
3. Heating low temperature capacity, Input Power and COP measured at 230 V, indoor temperature 20°C, outdoor 2/1°C.
4. Heating extreme low temperature capacity, Input Power and COP measured at 230 V, indoor temperature 20°C, outdoor -7/-8°C.
5. Specifications are subjected to change without prior notice for further improvement.

Model			Indoor	CS-Z50CD3EAW			CS-Z60CD3EAW		
			Outdoor	CU-Z50CBEA			CU-Z60CBEA		
Performance Test Condition				EUROVENT			EUROVENT		
Power Supply			Phase, Hz	Single, 50			Single, 50		
			V	230			230		
				Min.	Mid.	Max.	Min.	Mid.	Max.
Cooling	Capacity		kW	0.90	5.10	5.70	0.90	6.00	6.50
			BTU/h	3070	17400	19400	3070	20500	22200
			Kcal/h	770	4390	4900	770	5160	5590
	Running Current		A	-	6.90	-	-	9.00	-
	Input Power		W	255	1.56k	1.78k	255	2.04k	2.30k
	Annual Consumption		kWh	-	780	-	-	1020	-
	EER CLASS			-	A	-	-	C	-
	EER		W/W	3.53	3.27	3.20	3.53	2.94	2.83
			BTU/hW	12.04	11.15	10.90	12.04	10.05	9.65
			Kcal/hW	3.02	2.81	2.75	3.02	2.53	2.43
	ErP	Pdesign	kW	5.1			6.0		
		SEER	(W/W)	6.1			6.0		
		Annual Consumption	kWh	293			350		
		Class		A++			A+		
	Power Factor		%	-	98	-	-	99	-
	Indoor Noise (H / L / QLo)		dB(A)	39 / 29 / 26			41 / 30 / 27		
			Power Level dB(A)	58 / -			60 / -		
	Outdoor Noise (H / L)		dB(A)	48 / -			49 / -		
			Power Level dB(A)	63 / -			64 / -		
Heating	Capacity		kW	0.90	6.10	7.20	0.90	7.00	8.00
			BTU/h	3070	20800	24600	3070	23900	27300
			Kcal/h	770	5250	6190	770	6020	6880
	Running Current		A	-	8.00	-	-	9.70	-
	Input Power		W	260	1.82k	2.20k	260	2.16k	2.60k
	COP CLASS			-	C	-	-	C	-
	COP		W/W	3.46	3.35	3.27	3.46	3.24	3.08
			BTU/hW	11.81	11.43	11.18	11.81	11.06	10.50
			Kcal/hW	2.96	2.88	2.81	2.96	2.79	2.65
	ErP	Pdesign	kW	4.0			4.6		
		Tbivalent	°C	-10			-10		
		SCOP	(W/W)	4.1			4.1		
		Annual Consumption	kWh	1366			1571		
		Class		A+			A+		
	Power Factor		%	-	99	-	-	97	-
	Indoor Noise (H / L / QLo)		dB(A)	39 / 30 / 27			41 / 32 / 29		
			Power Level dB(A)	58 / -			60 / -		
	Outdoor Noise (H / L)		dB(A)	48 / -			50 / -		
			Power Level dB(A)	63 / -			65 / -		
Low Temp. : Capacity (kW) / I.Power (W) / COP				5.22 / 1.95k / 2.68			5.80 / 2.30k / 2.52		
Extr Low Temp. : Capacity (kW) / I.Power (W) / COP				4.50 / 1.95k / 2.31			5.10 / 2.32k / 2.20		

Model				Indoor	CS-Z50CD3EAW		CS-Z60CD3EAW	
				Outdoor	CU-Z50CBEA		CU-Z60CBEA	
Max Current (A) / Max Input Power (W)					9.9 / 2.20k		12.3 / 2.70k	
Starting Current (A)					8.00		9.70	
Compressor	Type				Hermetic Motor (Rotary)		Hermetic Motor (Rotary)	
	Motor Type				Brushless (4 poles)		Brushless (4 poles)	
	Output Power			W	900		900	
Maximum High Pressure				MPa (bar)	5.0 (50.0)		5.0 (50.0)	
Design / Operating Pressure, PS				MPa (bar) H.P. / L.P.	4.15 (41.5) / 2.55 (25.5)		4.15 (41.5) / 2.55 (25.5)	
Indoor Fan	Type				SIROCCO		SIROCCO	
	Material				GFZ010A / GF20		GFZ010A / GF20	
	Motor Type				DC Motor (8-poles)		DC Motor (8-poles)	
	Input Power			W	-		-	
	Output Power			W	51		51	
	Speed	QLo	Cool	rpm	920		920	
			Heat	rpm	920		920	
		Lo	Cool	rpm	940		980	
			Heat	rpm	980		1000	
		Me	Cool	rpm	1190		1230	
			Heat	rpm	1210		1240	
		Hi	Cool	rpm	1440		1480	
			Heat	rpm	1440		1480	
		SHi	Cool	rpm	1490		1530	
			Heat	rpm	1490		1530	
Outdoor Fan	Type				Propeller Fan		Propeller Fan	
	Material				PP		PP	
	Motor Type				DC Motor (8-poles)		DC Motor (8-poles)	
	Input Power			W	-		-	
	Output Power			W	40		40	
	Speed	Hi	Cool	rpm	720		770	
			Heat	rpm	660		720	
Moisture Removal				L/h (Pt/h)	2.8 (5.9)		3.3 (7.0)	
Indoor Airflow	QLo	Cool	m³/min (ft³/min.)	8.9 (314)		8.9 (314)		
		Heat	m³/min (ft³/min.)	8.9 (314)		8.7 (307)		
	Lo	Cool	m³/min (ft³/min.)	9.2 (325)		9.4 (332)		
		Heat	m³/min (ft³/min.)	9.6 (339)		9.7 (343)		
	Me	Cool	m³/min (ft³/min.)	12.1 (427)		12.6 (445)		
		Heat	m³/min (ft³/min.)	12.4 (438)		12.7 (448)		
	Hi	Cool	m³/min (ft³/min.)	15.30 (540)		15.70 (555)		
		Heat	m³/min (ft³/min.)	15.30 (540)		15.70 (555)		
	SHi	Cool	m³/min (ft³/min.)	15.9 (562)		16.4 (579)		
		Heat	m³/min (ft³/min.)	15.9 (562)		16.0 (565)		
Outdoor Airflow	Hi	Cool	m³/min (ft³/min.)	39.7 (1400)		42.6 (1505)		
		Heat	m³/min (ft³/min.)	36.4 (1285)		39.7 (1400)		
Refrigeration Cycle	Control Device			Expansion Valve		Expansion Valve		
	Refrigerant Oil		cm³	FW50S (450)		FW50S (450)		
	Refrigerant Type		kg (oz)	R32, 1.13 (39.9)		R32, 1.13 (39.9)		
F-Gas	GWP			675		675		
	CO2eq (ton) (Precharged Amount / Maximum Charged Amount)			0.76 / 0.99		0.76 / 0.99		

Model		Indoor	CS-Z50CD3EAW		CS-Z60CD3EAW	
		Outdoor	CU-Z50CBEA		CU-Z60CBEA	
Dimension	Height (I/D / O/D)	mm (inch)	200 (7-7/8) / 695 (27-3/8)		200 (7-7/8) / 695 (27-3/8)	
	Width (I/D / O/D)	mm (inch)	750 (29-17/32) / 875 (34-15/32)		750 (29-17/32) / 875 (34-15/32)	
	Depth (I/D / O/D)	mm (inch)	640 (25-7/32) / 320 (12-5/8)		640 (25-7/32) / 320 (12-5/8)	
Weight	Net (I/D / O/D)	kg (lb)	19 (42) / 43 (95)		19 (42) / 43 (95)	
Piping	Pipe Diameter (Liquid / Gas)	mm (inch)	6.35 (1/4) / 12.70 (1/2)		6.35 (1/4) / 12.70 (1/2)	
	Standard length	m (ft)	5.0 (16.4)		5.0 (16.4)	
	Length range (min – max)	m (ft)	3 (9.8) ~ 30 (98.4)		3 (9.8) ~ 30 (98.4)	
	I/D & O/D Height different	m (ft)	20.0 (65.6)		20.0 (65.6)	
	Additional Gas Amount	g/m (oz/ft)	15 (0.2)		15 (0.2)	
	Length for Additional Gas	m (ft)	7.5 (24.6)		7.5 (24.6)	
Drain Hose	Inner Diameter	mm	16		16	
	Length	mm	117.5		117.5	
Indoor Heat Exchanger	Fin Material		Aluminium (Pre Coat)		Aluminium (Pre Coat)	
	Fin Type		Slit Fin		Slit Fin	
	Row × Stage × FPI		3 × 12 × 18		3 × 12 × 18	
	Size (W × H × L)	mm	590 × 282 × 38.1		590 × 282 × 38.1	
Outdoor Heat Exchanger	Fin Material		Aluminium		Aluminium	
	Fin Type		Corrugated Fin (Pre Coat)		Corrugated Fin (Pre Coat)	
	Row × Stage × FPI		2 × 31 × 19		2 × 31 × 19	
	Size (W × H × L)	mm	36.4 × 651 × 854.5:824.5		36.4 × 651 × 854.5:824.5	
Air Filter	Material		-		-	
	Type		-		-	
Power Supply			Outdoor		Outdoor	
Power Supply Cord		A	Nil		Nil	
Thermostat			Electronic Contol		Electronic Contol	
Protection Device			Electronic Contol		Electronic Contol	
			Dry Bulb	Wet Bulb	Dry Bulb	Wet Bulb
Indoor Operation Range	Cooling	Maximum °C	32	23	32	23
		Minimum °C	16	11	16	11
	Heating	Maximum °C	30	-	30	-
		Minimum °C	16	-	16	-
Outdoor Operation Range	Cooling	Maximum °C	43	26	43	26
		Minimum °C	-10	-	-10	-
	Heating	Maximum °C	24	18	24	18
		Minimum °C	-15	-16	-15	-16

1. Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and outdoor air temperature of 35°C Dry Bulb (95°F Dry Bulb), 24°C Wet Bulb (75.2°F Wet Bulb).
2. Heating capacities are based on indoor temperature of 20°C Dry Bulb (68°F Dry Bulb) and outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb).
3. Heating low temperature capacity, Input Power and COP measured at 230 V, indoor temperature 20°C, outdoor 2/1°C.
4. Heating extreme low temperature capacity, Input Power and COP measured at 230 V, indoor temperature 20°C, outdoor -7/-8°C.
5. Specifications are subjected to change without prior notice for further improvement.

- **Multi Split Combination Possibility:**

- A single outdoor unit enables air conditioning of up to two separate rooms for CU-2Z35CBE, CU-2Z41CBE, CU-2Z50CBE.
- A single outdoor unit enables air conditioning of up to three separate rooms for CU-3Z68CBE, CU-3Z52CBE.

CONNECTABLE INDOOR UNIT			CU-2Z35CBE		CU-2Z41CBE		CU-2Z50CBE		CU-3Z68CBE			CU-3Z52CBE		
ROOM			A	B	A	B	A	B	A	B	C	A	B	C
Wall	2.0kW	CS-MZ20CD3EA	●	●	●	●	●	●	●	●	●	●	●	●
	2.5kW	CS-Z25CD3EAW	●	●	●	●	●	●	●	●	●	●	●	●
	3.5kW	CS-Z35CD3EAW	●	—	●	—	●	●	●	●	●	●	●	—
	5.0kW	CS-Z50CD3EAW	—	—	—	—	●	—	●	●	—	●	—	—
	6.0kW	CS-Z60CD3EAW	—	—	—	—	—	—	●	—	—	—	—	—
Capacity range of connectable units			From 3.2kW to 6.0kW		From 3.2kW to 6.0kW		From 3.2kW to 7.7kW		From 4.5kW to 11.2kW			From 4.5kW to 9.5kW		
Pipe length	1 room maximum pipe length (m)		20		20		20		25			25		
	Allowable elevation (m)		10		10		10		15			15		
	Total allowable pipe length (m)		30		30		30		60			50		
	Total pipe length for maximum chargeless length (m)		20		20		20		30			30		
	Additional gas amount over chargeless length (g/m)		15		15		15		20			20		
Note: “●” : Available														
Remarks for CU-2Z35CBE / CU-2Z41CBE / CU-2Z50CBE 1. At least two indoor units must be connected. 2. The total nominal cooling capacity of indoor unit that will be connected to outdoor unit must be within connectable capacity range of indoor unit. (as shown in the table above) Example: The indoor units' combination below is possible to connect to CU-2Z41CBE. (Total nominal capacity of indoor units is between 3.2kW to 6.0kW) 1) Two CS-MZ20CD3EA only. (Total nominal cooling capacity is 4.0kW)														
Remarks for CU-3Z68CBE / CU-3Z52CBE 1. At least two indoor units must be connected. 2. The total nominal cooling capacity of indoor unit that will be connected to outdoor unit must be within connectable capacity range of indoor unit. (as shown in the table above) Example: The indoor units' combination below is possible to connect to CU-3Z68CBE. (Total nominal capacity of indoor units is between 4.5kW to 11.2kW) 1) Two CS-Z25CD3EAW only. (Total nominal cooling capacity is 5.0kW)														

- **Multi Split Combination Possibility:**

- A single outdoor unit enables air conditioning of up to four separate rooms for CU-4Z68CBE, CU-4Z80CBE.
- A single outdoor unit enables air conditioning of up to five separate rooms for CU-5Z90CBE.


CONNECTABLE INDOOR UNIT			CU-4Z68CBE				CU-4Z80CBE				CU-5Z90CBE				
ROOM			A	B	C	D	A	B	C	D	A	B	C	D	E
Wall	2.0kW	CS-MZ20CD3EA	●	●	●	●	●	●	●	●	●	●	●	●	●
	2.5kW	CS-Z25CD3EAW	●	●	●	●	●	●	●	●	●	●	●	●	●
	3.5kW	CS-Z35CD3EAW	●	●	●	—	●	●	●	●	●	●	●	●	●
	5.0kW	CS-Z50CD3EAW	●	●	—	—	●	●	—	—	●	●	●	—	—
	6.0kW	CS-Z60CD3EAW	●	—	—	—	●	●	—	—	●	●	—	—	—
Capacity range of connectable units			From 4.5kW to 11.5kW				From 4.5kW to 14.7kW				From 4.5kW to 18.3kW				
Pipe length	1 room maximum pipe length (m)		25				25				25				
	Allowable elevation (m)		15				15				15				
	Total allowable pipe length (m)		60				70				80				
	Total pipe length for maximum chargeless length (m)		30				45				45				
	Additional gas amount over chargeless length (g/m)		20				20				20				
Note: “●” : Available															
Remarks for CU-4Z68CBE / CU-4Z80CBE / CU-5Z90CBE 1. At least two indoor units must be connected. 2. The total nominal cooling capacity of indoor unit that will be connected to outdoor unit must be within connectable capacity range of indoor unit. (as shown in the table above) Example: The indoor units' combination below is possible to connect to CU-4Z80CBE. (Total nominal capacity of indoor units is between 4.5kW to 14.7kW) 1) Two CS-Z25CD3EAW only. (Total nominal cooling capacity is 5.0kW)															

4. Features


- **Inverter Technology**
 - Wider output power range
 - Energy saving
 - Quick Cooling
 - Quick Heating
 - More precise temperature control
- **Environment Protection**
 - Non-ozone depletion substances refrigerant (R32)
- **Long Installation Piping**
 - Long piping up to 20 meters (1.0 ~ 1.5HP) and 30 meters (2.0 ~ 2.25HP) during single split connection only
- **Easy to use remote control**
- **Quality Improvement**
 - Random auto restart after power failure for safety restart operation
 - Gas leakage protection
 - Prevent compressor reverse cycle
 - Inner protector to protect compressor
 - Noise prevention during soft dry operation
- **Operation Improvement**
 - Quiet mode to reduce the indoor unit operating sound
 - Powerful mode to reach the desired room temperature quickly
 - 24-hour timer setting
- **Serviceability Feature**
 - Breakdown Self Diagnosis function

5. Location of Controls and Components

5.1 Indoor Unit



5.2 Outdoor Unit




5.3 Remote Control


5.3.1 Remote Control Buttons and Display

Buttons / Indicator


- | | |
|---|--|
| ① | Quick Menu button |
| ② | Back button
Returns to the previous screen |
| ③ | LCD Display |
| ④ | Main Menu button
For function setup |
| ⑤ | ON/OFF button
Starts/Stops operation |
| ⑥ | Operation indicator
Illuminates during operation, blinks during alarm. |




! Press centre



⊘ No glove




⊘ No pen




Cross key buttons

Selects an item.



5.3.2 Quick Menu



① Press .

② Use     to select quick menu.

③ Press  to turn on/off the select mode.

To return to the Main Screen, Press  or .

Quick Menu



Powerful



Quiet



Weekly timer



LED intensity dim



R/C Lock




AC Reset



RC Reset

Select each setting and confirm the setting according to the instructions displayed at the bottom of the screen. (The icons refer to each selection key.)


Basic operation



- ① Press to start/stop the operation.
- ② Press to select either mode, set temperature or fan speed section.
 - Use or to select setting.
 - Press to confirm the selection.

Mode section

Default setting for Mode is AUTO.



Set temperature section

Selection range:

16.0 °C ~ 30.0 °C / 60 °F ~ 86 °F.

- Not available during Fan Mode.


Fan speed section

- When FAN AUTO is selected, the fan speed is adjusted automatically according to the operation mode.
- Select the lowest fan speed to have a low noise operation.



6. Dimensions


6.1 Indoor Unit




Unit: mm

6.2 Outdoor Unit


6.2.1 CU-Z25CBEA



6.2.2 CU-Z35CBEA




CU-Z50CBEA CU-Z60CBEA




7. Refrigeration Cycle Diagram

7.1 CS-Z25CD3EAW CU-Z25CBEA CS-Z35CD3EAW CU-Z35CBEA




7.2 CS-Z50CD3EAW CU-Z50CBEA CS-Z60CD3EAW CU-Z60CBEA




8. Block Diagram

8.1 CS-Z25CD3EAW CU-Z25CBEA CS-Z35CD3EAW CU-Z35CBEA




9. Wiring Connection Diagram

9.1 Indoor Unit



9.2 Outdoor Unit

9.2.1 CU-Z25CBEA CU-Z35CBEA




Resistance of Compressor Windings

MODEL	CU-Z25CBEA / CU-Z35CBEA
CONNECTION	9RS102XFA21 (Ω)
U-V	1.211
U-W	1.211
V-W	1.211

Note: Resistance at 20°C of ambient temperature.

9.2.2 CU-Z50CBEA CU-Z60CBEA






Resistance of Compressor Windings

MODEL	CU-Z50CBEA / CU-Z60CBEA
CONNECTION	9RD132XAA21 (Ω)
U-V	1.897
U-W	1.907
V-W	1.882




Note: Resistance at 20°C of ambient temperature.

10.2 Outdoor Unit

10.2.1 CU-Z25CBEA CU-Z35CBEA



10.2.2 CU-Z50CBEA CU-Z60CBEA




11.1.1 Main Printed Circuit Board




11.2 Outdoor Unit

11.2.1 Main Printed Circuit Board

11.2.1.1 CU-Z25CBEA CU-Z35CBEA



11.2.1.2 CU-Z50CBEA CU-Z60CBEA



12. Installation Instruction

■ Required Materials

- Read the catalog and other technical materials and prepare the required materials.
- Applicable piping kit

Applicable piping kit	Piping size	
	Gas	Liquid
CZ-3F5, 7BP	9.52 mm (3/8")	6.35 mm (1/4")
CZ-4F5, 7, 10BP	12.7 mm (1/2")	6.35 mm (1/4")
CZ-52F5, 7, 10BP	15.88 mm (5/8")	6.35 mm (1/4")

- Pipe Size Reducer (CZ-MA1PA) and Expander (CZ-MA2PA) for Outdoor Multi Connection CS-Z50***, CS-Z60***.
- Please refer to "CONNECT THE PIPING" section.

■ Other Items to be Prepared (Locally Purchased)

Product name	Remarks
Rigid PVC pipe	VP-20 (outer diameter ø26); also sockets, elbows and other parts as necessary
Adhesive	PVC adhesive
Insulation	For refrigerant piping insulation : foamed polyethylene with a thickness of 8 mm or more. For drain piping insulation : foamed polyethylene with a thickness of 10 mm or more.
Indoor/outdoor connecting cable	4 × 1.5 mm ² flexible cord, designation type 60245 IEC 57 (H05RN-F)
Hanging bolt related parts	Hanging bolts (M10) (4) and nuts (12), (when hanging the indoor unit)

Table A

Model	Capacity W (HP)	Max. Refrigerant Charge (kg)	Indoor A _{min} (m ²)
MZ20***	3/4HP	Refer to Installation Instruction at outdoor unit	
Z25***	1.0HP	1.01	Not applicable (*)
Z35***	1.5HP	1.10	Not applicable (*)
Z50***	2.0HP	1.47	Not applicable (*)
Z60***	2.25HP	1.47	Not applicable (*)

(*) Systems with total refrigerant charge, m_c , lower than 1.84 kg are not subjected to any room area requirements.

* Table "A" only applicable for single split connection.

* In case of connection to outdoor multi inverter, refer to installation manual at outdoor unit.

$$A_{\min} = (m_c / (2.5 \times (LFL)^{(5/4)} \times h_0))^2$$

$A_{\min}$ = Required minimum room area, in m²

m_c = Refrigerant charge in appliance, in kg

LFL = Lower flammability limit (0.307 kg/m³)





h_0 = Installation height of the appliance (2.2 m for ducted)

CF = Concentration factor with a value of 0.75

** The required minimum room area, $A_{\min}$, shall also be governed by the concentration factor margin formula below :

$$A_{\min} = m_c / (CF \times LFL \times h_0)$$

The higher value shall be taken when determining the room area.



IMPORTANT

Begin the installation job from the "Indoor Unit" installation.

- This illustration is for explanation purposes only. The indoor unit will actually face a different way.

12.1 Indoor Unit

12.1.1 Selecting the Installation Location

Take into consideration the following contents when creating the blueprint.

■ Indoor unit installation location

- Do not install the unit in excessive oil fume area such as kitchen, workshop and etc.
- The location should be strong enough to support the main unit without vibration.
- There should not be any heat or steam source nearby.
- Drainage should be easy. Avoid locating the drain port close to ditches (domestic wastewater).
- Avoid locations above entrances and exits.
- Do not block the air intake and discharge passages.
- Select the location that enables the cool and warm air to spread out to the entire room.
- Locate the indoor unit at least 1 m or more away from a TV, radio, wireless appliance, antenna cable and fluorescent light, and 2 m or more away from a telephone.
- Indoor unit of this air conditioner shall be installed in a height of at least 2.2 m.

12.1.2 To Drill a Hole in the Wall and Install a Sleeve of Piping


- 1 Insert the piping sleeve to the hole.
- 2 Fix the bushing to the sleeve.
- 3 Cut the sleeve until it extrudes about 15 mm from the wall.



CAUTION

When the wall is hollow, be sure to use the sleeve for tube assembly to prevent pests from damaging the cables, e.g. mice biting the connection cable.

- 4 Finish by sealing the sleeve with putty or caulking compound at the final stage.



12.1.3 Installing the Indoor Unit (Installation Embedded in the Ceiling)

12.1.3.1 Preparation Before Installation

- Always provide sufficient entry and exit space to allow installation work, inspection and unit replacement.
- Waterproof the rear surface of the ceiling below the unit in consideration of water droplets forming and dropping.


⚠ CAUTION

When cooling operation is performed for an extended period under the following conditions, water droplets may form and drop. Attach locally purchased insulation (foamed polyethylene with a thickness of 5 mm or more) to the outside of the indoor unit before installing into the ceiling to improve heat insulation.

- Locations with a dew point inside the ceiling of 23°C or more
- Kitchens and other locations that produce large amounts of heat and steam
- Locations where the inside of the ceiling serves as an outside air intake passage


- **When installing into a ceiling, select the unit position and airflow direction that enable the cool and warm air to spread out to the whole room.**
- **Do not place objects that might obstruct the airflow within 1 m below the intake grill.**

Required Minimum Space for installation and Service




- H dimension means the minimum height of the unit installation space.
- Select H dimension such that a downward slope of at least 1/100 is ensured. Refer to 12.1.4 "Connecting the drain piping"

Dimension of the indoor unit




In case of Bottom Intake

- 1 Remove the frame filter assy as shown in diagram ①
- 2 Remove cover plate as shown in diagram ①
- 3 Fix frame filter assy as shown in diagram ②
- 4 Fix cover plate as shown in diagram ② with the dummy hole downward.



Fixing Frame Filter Assy




In case of bottom side

* Attach the frame filter assy to the main unit while pushing the tip of the latches in the direction of the arrow.


In case of back side

Ceiling Opening

- Install inspection opening (450 mm × 450 mm) on the control box side where maintenance and inspection of the control box and drain pump are easy. Install another inspection opening (800 mm × 700 mm) also at the lower part of the unit.




Securing the Hanging Bolts



- Secure the hanging bolts (M10, locally purchased) firmly in a manner capable of supporting the unit weight.
- Consult your construction or interior contractor for details on finishing the ceiling opening.

Installing an Intake and Discharge Duct Type

- Ensure the range of unit external static pressure is not exceeded. Refer technical manual for the range of external static pressure setting.
- Connect the duct as shown.
- When attaching duct to the intake side, remove the product filter frame assy and replace with locally purchase intake-side flange by using flange by using 10 - Ø3.1(hole) screws.
- Wrap the flange and duct connection area with aluminium tape or similar to prevent air leak.




CAUTION

When attaching a duct to the intake-side, be sure to attach an air filter inside the air passage on the intake-side. (Use an air filter with dust collecting efficiency at least 50% in a gravimetric technique.)

Installation into the Ceiling

- Attach the nuts and washers to the hanging bolts, then lift up and hook the main unit onto the hanging fixtures.
- Check if the unit is leveled using a level or a vinyl hose filled partially with water.




Remote Controller Installation

⚠ CAUTION

Install the remote controller cable at least 5 cm away from electric wires of other appliances to avoid miss-operation (electromagnetic noise).


■ Remote Controller Mounting Location

- Allow sufficient space around the remote controller **1** as shown in the illustration at right.
- Install in a place which is away from direct sunlight and high humidity.
- Install in a flat surface to avoid warping of the remote controller. If installed to a wall with an uneven surface, damage to the LCD case or operation problems may result.
- Install in a place where the LCD can be easily seen for operation.
(Standard height from the floor is 1.2 to 1.5 meters.)
- Avoid installing the remote controller cable near refrigerant pipes or drain pipes, else it will cause electrical shock or fire.




■ Remote Controller Installation

- Remove the remote controller **1** lower case.
(Insert a flat-tipped screw driver or similar tool 2 to 3 mm into the gap at the bottom of the case, and twist to open. Refer to the illustration at below.) Be careful not to damage the lower case.
- Do not remove the protective film which is affixed to the upper case circuit board when remove the remote controller lower case.
- Secure the lower case to an outlet box or wall. Refer to (A) or (B) instructions below depending on your choice of cable installation.
- Be sure to use only the screws provided.
- Do not over tighten the screws, as it may result in damage to the lower case.



- Connect the indoor unit and the remote controller [1]. (Refer to the illustration)
- Insert firmly the connector of remote controller cable [2] to connector at control box of indoor unit.
- Fix the green wire from remote controller cable [2] to the grounding location provided inside control board.




A. IF REMOTE CONTROLLER CABLE IS EMBEDDED

- 1 Embed an outlet box (JIS C 8336) into the wall. Outlet box maybe purchased separately. Medium size square outlet box (obtain locally) Part No. DS3744 (Panasonic Co., Ltd.) or equivalent.
- 2 Secure the remote controller lower case to the outlet box with the three accessory screws [3]. Make sure that the lower case is flat against the wall at this time, with no bending.
- 3 Pass the remote controller cable [2] into the box.
- 4 Route the remote controller cable [2] inside the lower case through rear feeding-out direction.
- 5 Insert firmly the connector of remote controller cable [2] to connector (CN-RMT) in the upper case circuit board. (Refer to the illustration at below.)
- 6 Secure the remote controller upper case to the lower case with the tabs provided.


⚠ CAUTION

When the wall is hollow, please be sure to use the sleeve for remote controller cable to prevent dangers caused by mice biting the cable.




B. IF REMOTE CONTROLLER CABLE IS EXPOSED

- 1 Install the remote controller lower case to the wall with the three accessory screws [4].
- 2 Fasten the screws properly until screw head is lower than the rib and reach the base of remote controller lower case to ensure they do not damage the PCB inside the remote controller [1].
- 3 The feeding-out direction for the remote controller cable shall be via the top side.
- 4 Use nipper to cut a notch at the upper case.
- 5 Route the remote controller cable [2] inside the upper case. (Refer to the illustration at below).
- 6 Insert firmly the connector of remote controller cable [2] to connector (CN-RMT) in the upper case circuit board. (Refer to the illustration at below)
- 7 Secure the remote controller upper case to the lower case with the tabs provided.



12.1.4 Connecting the Drain Piping

- Lay the drain piping so as to ensure drainage.
- Use a locally purchased VP-20 general rigid PVC pipe (outer diameter $\varnothing 26$) for the drain piping **and firmly connect the indoor unit and the drain piping using supplied hose band to ensure that no leakage occurs.**
- Drain piping located indoor should always be insulated by wrapping with locally purchased insulation (foamed polyethylene with a thickness of 10 mm or more).
- The drain piping should have a downward gradient (1/100 or more) and should be secured by using pipe hanging equipment to avoid creating hills or traps partway.
- Should there be any obstacle preventing the drain piping from being extended smoothly, the drain piping can be raised outside of the main unit as shown in the illustration below.




⚠ CAUTION

- Strictly do not install and extend the drain piping from the main unit drain water outlet horizontally or upward or raised it 50 cm or more. Doing so may result in poor drainage or drain motor failure.
- Do not use drain hose bent at 90° angle. (The maximum permissible bend is 45°.)

12.1.5 Insulating the Refrigerant Piping

- After the piping is connected, insulate. (Refer to the illustration)



12.1.6 Connecting the Indoor/Outdoor Connection Cable

- Remove the control box cover and insert the connection cable into the control box.
- Check the color of the wires on the terminal board and secure them with screws.
- Secure the outer sheath of the connection cable with the cord clamp.
- Reattach the control box cover to its original position.



CAUTION

When the wall is hollow, please be sure to use the sleeve for tube ass'y to prevent dangers caused by mice biting the connection cable.

- Connection cable between indoor unit and outdoor unit should be approved polychloroprene sheathed $4 \times 1.5 \text{ mm}^2$ flexible cord, designation type 60245 IEC 57 (H05RN-F) or heavier cord. Allowable connection cable length of each indoor unit shall be 30 m or less.
 - Ensure that the terminal numbers on the indoor unit are connected to the same terminal numbers on the outdoor unit by the right coloured wires as shown in the diagram.
 - Earth lead wire should be longer than the other lead wires as shown in the diagram for electrical safety purpose in case the cord slips out from the anchorage.
 - Secure the cable onto the control board with the holder (clammer).

Terminals on the indoor unit	1	2	3	
Colour of wires				
Terminals on the outdoor unit	1	2	3	


- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
- Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires for safety reason.




WARNING



This equipment must be properly earthed.




12.1.6.1 Wire Stripping and Connecting Requirement



Do not joint wires



- ❗ Use complete wire without joining.
- ❗ Use approved socket and plug with earth pin.
- ❗ Wire connection in this area must follow to national wiring rules.



12.1.7 Connect the Piping


12.1.7.1 Connecting the Piping to Indoor

For connection joint of all models

Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe. (In case of using long piping)

Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.




Additional Precautions For R32 Models when connecting by flaring at indoor side



Ensure to do the re-flaring of pipes before connecting to units to avoid leaking.

Seal sufficiently the flare nut (both gas and liquid sides) with neutral cure (Alkoxy type) & ammonia-free silicone sealant and insulation material to avoid the gas leak caused by freezing.



Neutral cure (Alkoxy type) & ammonia-free silicone sealant is only to be applied after pressure testing and cleaning up by following instructions of sealant, only to the outside of the connection. The aim is to prevent moisture from entering the connection joint and possible occurrence of freezing. Curing sealant will take some time. Make sure sealant will not peel off when wrapping the insulation.

12.1.7.2 Connecting the Piping to Outdoor

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge.

Make flare after inserting the flare nut (locate at valve) onto the copper pipe.

Align center of piping to valve and then tighten with torque wrench to the specified torque as stated in the table.



Do not overtighten, overtightening may cause gas leakage.

Piping size	Torque
6.35 mm (1/4")	[18 N•m (1.8 kgf•m)]
9.52 mm (3/8")	[42 N•m (4.3 kgf•m)]
12.7 mm (1/2")	[55 N•m (5.6 kgf•m)]
15.88 mm (5/8")	[65 N•m (6.6 kgf•m)]
19.05 mm (3/4")	[100 N•m (10.2 kgf•m)]


12.1.7.3 Connecting the Piping to Outdoor Multi

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge.

Make flare after inserting the flare nut (locate at valve) onto the copper pipe. Align center of piping to valve and then tighten with torque wrench to the specified torque as stated in the table.


* For Gas side piping please refer table and diagram below

Outdoor Multi Combination Model		Pipe size (refer to diagram)
	R32 Model	
CS-MZ20***, CS-Z25***, CS-Z35***	CU-2Z35***, CU-2Z41***, CU-2Z50***, CU-3Z52***, CU-3Z68***, CU-4Z68***, CU-4Z80***, CU-5Z90***, CU-4WZ90***	①
CS-Z50***	CU-2Z50***, CU-3Z52***, CU-3Z68***, CU-4Z68***, CU-4Z80***, CU-5Z90***, CU-4WZ90***	② (CZ-MA1PA)
CS-Z60***	CU-3Z68***, CU-4Z68***, CU-4Z80***, CU-5Z90***, CU-4WZ90***	③ (CZ-MA2PA)




12.1.7.4 Cutting and Flaring the Piping


1. Please cut using pipe cutter and then remove the burrs.
2. Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused.
Turn the piping end down to avoid the metal powder entering the pipe.
3. Please make flare after inserting the flare nut onto the copper pipes.





1. To cut



2. To remove burrs



3. To flare



When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

12.1.8 Switching the High State Switch (SW2)

- To increase the air volume, open the control box and on the control board, switch the FAN switch (SW2) to "HI".
- See the diagram for "Connecting the Indoor/Outdoor Connection Cable".

12.1.9 Note: Enabling long-range remote controller

- To maintain EMC emission limits, cabling interconnecting the HA terminal and subsequent opto-coupler, must be no more than 1.9 m length.
- Loop four turns of this cable through a suitable small EMC ferrite toroid, and protect with a short length of large diameter heat-shrink tube.
- There is no similar length limit for cable following on from the opto-coupler isolation.


12.1.10 Check the Drainage

Check after connecting the power supply.

- Pour approximately 600 cc of water into the drain pan of the main unit using a squeeze bottle, etc.
- Press the drain test run switch on the control board in the control box to start the drain motor and check whether the water drains normally.

(The drain motor operates for approximately 5 minutes and then stops automatically.)

(See the diagram for "Connecting the Indoor/Outdoor Connection Cable".)



12.2 Outdoor Unit

12.2.1 Select the Best Location

- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over the [piping length for additional gas], additional refrigerant should be added as shown in the table.

Table A

Model	Capacity W (HP)	Piping size		Std. Length (A) (m)	Max Elevation (B) (m)	Min. Piping Length (m)	Max. Piping Length (m)	Additional Refrigerant (g/m)	Piping Length for add. gas (m)	Max. Refrigerant Charge (kg)	Ducted Indoor A_{min} (m ²)	Floor Console Indoor A_{min} (m ²)
		Gas	Liquid									
Z25****	1.0HP	9.52 mm (3/8")	6.35 mm (1/4")	5	15	3	20	10	7.5	1.01	Not applicable (*)	Not applicable (*)
Z35****	1.5HP				15	3	20	10	7.5	1.10	Not applicable (*)	Not applicable (*)
Z50****	2.0HP	12.7 mm (1/2")			20	3	30	15	7.5	1.47	Not applicable (*)	Not applicable (*)
Z60****	2.25HP				20	3	30	15	7.5	1.47	Not applicable (*)	N/A

(*) Systems with total refrigerant charge, m_c lower than 1.84 kg are not subjected to any room area requirements.

Example: For Z25****

If the unit is installed at 10 m distance, the quantity of additional refrigerant should be 25 g $(10-7.5) \text{ m} \times 10 \text{ g/m}$
= 25 g.

$$A_{min} = (m_c / (2.5 \times (LFL)^{(5/4)} \times h_0))^2$$

** not less than concentration factor margin

A_{min} = Required minimum room area, in m²

m_c = Refrigerant charge in appliance, in kg

LFL = Lower flammability limit (0.307 kg/m³)


h_0 = Installation height of the appliance (2.2 m for Ducted)
(0.6 m for Floor Console)

CF = Concentration factor with a value of 0.75

** The required minimum room area, A_{min} , shall also be governed by the concentration factor margin formula below :

$$A_{min} = m_c / (CF \times LFL \times h_0)$$

The higher value shall be taken when determining the room area.




- This illustration is for explanation purposes only.

12.2.2 Install the Outdoor Unit

- After selecting the best location, start installation according to Indoor/Outdoor Unit Installation Diagram.
 - Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut ($\phi 10$ mm).
Make sure unit install in balance level to ensure that water flow out from unit drainage hole.
 - When installing at roof, please consider strong wind and earthquake.
Please fasten the installation stand firmly with bolt, screws or nails.

Model	A	B	C	D
Z25****	570 mm	105 mm	18.5 mm	320 mm
Z35****	540 mm	160 mm	18.5 mm	330 mm
Z50****	613 mm	131 mm	24 mm	360.5 mm
Z60****				



12.2.3 Connect the Piping

12.2.3.1 Connecting the Piping to Indoor


For connection joint location at outside building
Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe.
(In case of using long piping)

For connection joint location at inside building

- Refer to indoor installation instruction.

Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.



12.2.3.2 Connecting the Piping to Outdoor

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge.

Make flare after inserting the flare nut (locate at valve) onto the copper pipe.

Align center of piping to valve and then tighten with torque wrench to the specified torque as stated in the table.

⊘ Do not overtighten, overtightening may cause gas leakage.	
Piping size	Torque
6.35 mm (1/4")	[18 N•m (1.8 kgf•m)]
9.52 mm (3/8")	[42 N•m (4.3 kgf•m)]
12.7 mm (1/2")	[55 N•m (5.6 kgf•m)]
15.88 mm (5/8")	[65 N•m (6.6 kgf•m)]
19.05 mm (3/4")	[100 N•m (10.2 kgf•m)]

12.2.4 Air Tightness Test on the Refrigerating System




Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation.



There is no extra refrigerant in the outdoor unit for air purging.

- Before system is charged with refrigerant and before the refrigerating system is put into operation, below site test procedure and acceptance criteria shall be verified by the certified technicians, and/or the installer.
- Be sure to check whole system for gas leakage.



Notes: Recommended use of any of the following leak detector,


- I) Universal Sniffer leak detector
- II) Electronic halogen leak detector
- III) Ultrasonic Leak Detector

12.2.5 Connect the Cable to the Outdoor Unit


(FOR DETAIL REFER TO WIRING DIAGRAM AT UNIT)

- Remove the control board cover from the unit by loosening the screw.
- Cable connection to the power supply through Isolating Devices (Disconnecting means).
 - Connect approved type polychloroprene sheathed **power supply cord** $3 \times 1.5 \text{ mm}^2$ (1.0 ~ 1.5HP), $3 \times 2.5 \text{ mm}^2$ (2.0 ~ 2.25HP) type designation 60245 IEC 57 or heavier cord to the terminal board, and connect the others end of the cord to Isolating Devices (Disconnecting means).
 - Do not use joint power supply cord. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.
 - In unavoidable case, joining of power supply cord between isolating devices and terminal board of air conditioner shall be done by using approved socket and plug with earth pin rated 15/16 A (1.0 ~ 1.5HP), 16 A (2.0 ~ 2.25HP).

Wiring work to both socket and plug must follow to national wiring standard.
- Connection cable** between indoor unit and outdoor unit shall be approved polychloroprene sheathed $4 \times 1.5 \text{ mm}^2$ flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short. Allowable connection cable length of each indoor unit shall be 30 m or less.
- Connect the power supply cord and connection cable between indoor unit and outdoor unit according to the diagram below.



- Secure the power supply cord and connection cable onto the control board with the holder.
- Attach the control board cover back to the original position with screw.
- For wire stripping and connection requirement, refer to instruction 12.1.6 of indoor unit.
 - Note: Isolating Devices (Disconnecting means) should have minimum 3.0 mm contact gap.
 - Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires for safety reason.
 - Always ensure all above connections compliant with national wire rules.




12.2.6 Piping Insulation

- 1 Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
- 2 If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 6 mm or above.

12.2.6.1 Disposal of Outdoor Unit Drain Water

- If a drain elbow is used, the unit should be placed on a stand which is taller than 3 cm.
- If the unit is used in an area where temperature falls below 0°C for 2 or 3 days in succession, it is recommended not to use a drain elbow, for the drain water freezes and the fan will not rotate.



12.2.6.2 In Case of Reusing Existing Refrigerant Piping

- Observe the followings to decide reusing the existing refrigerant piping. Poor refrigerant piping could result in product failure.
 - In the circumstances listed below, do not reuse any refrigerant piping. Instead, make sure to install a new piping.
 - Heat insulation is not provided for either liquid-side or gas-side piping or both.
 - The existing refrigerant pipe has been left in an open condition.
 - The diameter and thickness of the existing refrigerant piping does not meet the requirement.
 - The piping length and elevation does not meet the requirement.Perform proper pump down before reuse piping.
 - In the circumstances listed below, clean it thoroughly before reuse.
 - Pump down operation cannot be performed for the existing air-conditioner.
 - The compressor has a failure history.
 - Oil color is darken. (ASTM 4.0 and above).
 - The existing air-conditioner is gas/oil heat pump type.
 - Do not reuse the flare to prevent gas leak. Make sure to install a new flare.
 - If there is a welded part on the existing refrigerant piping, conduct a gas leak check on the welded part.
 - Replace deteriorated heat insulating material with a new one.
Heat insulating material is required for both liquid-side and gas-side piping.

12.2.6.3 Proper Pump Down Method

- ① Operate air conditioner at cooling mode for 10 ~ 15 minutes.

Most Important Process
Purpose: To make the oil & refrigerant mix together. They are in separated condition when air conditioner is stopped.


- ② After 10 ~ 15 minutes of pre operation, close 2 way valve. After 3 minutes, close 3 way valve.

Mixed refrigerant & oil will be collected into outdoor unit.

- ③ Take out air conditioner unit.

Only very small amount of oil remain inside piping, which is acceptable.

- ④ Install New Refrigerant air conditioner.



13. Installation and Servicing Air Conditioner using R32

13.1 About R32 Refrigerant

For air conditioning refrigerants such as R410A, the refrigerants were collected back in order to prevent their air dissipation, to curb the global warming impact, in case they were released into the atmosphere. In the “4th Environmental Basic Plan”, 80% reduction of greenhouse gas emissions by 2050 is required, and due to this requirement, further reduction in the emission of high greenhouse effect gas, such as CFCs, is required. Therefore, the conversion of air conditioning refrigerant into the ones who has smaller greenhouse effect, even if it is dissipated into the atmosphere, became our responsibility.

Nevertheless, in case of air conditioning refrigerant, it would be the best if there is a refrigerant which has smaller impact on global warming, but ensures good energy efficiency and performance, and is safe; however, there is no such refrigerant which satisfies all these conditions. As a result, we have been considering the practical usage, within the safety frame-work, of R32 refrigerant which has short lifetime in the atmosphere, and has smaller effect of global warming, but is slightly flammable.

In 2004, due to the revision of air conditioner safety standards by the International Electro-safety Commission (IEC), the safety standards of air conditioners using slightly flammable refrigerant was issued. In 2010, the regulations of American Society of Heating, Refrigerating and Air-Conditioning Engineers in the United States (ANSI/ASHRAE34) was issued adopting the grades for refrigerants which are difficult to inflame due to their slow burning rates, and as a result have smaller damages in cases of fire. The burning rate of R32 is lower by 10cm / per second, and safety standardization for various usage is now being processed.

13.2 Characteristics of R32 Refrigerant

1. Chemical Characteristics

R32 is one of the refrigerants used in R410A, has almost no toxicity, and chemically stable compound formed by hydrogen, carbon and fluorine.

R32 has short lifetime of 4 to 9 years in case of being released into the atmosphere; therefore, it has smaller greenhouse gas effect but has slight inflammability because of the large proportion of hydrogen.

Chemical Characteristic Table of R32, R410A and R22.

	R32	R410A	R22
Chemical Formula	CH ₂ F ₂	CH ₂ F ₂ / CHF ₂ CF ₃	CHClF ₂
Composition (mixture ratio wt.%)	Single Composition	R32 / R125A (50 / 50 wt.%)	Single Composition
Boiling Point (°C)	-51.7	-51.5	-40.8
Pressure (physical) *1	3.14	3.07	1.94
Capacity (physical) *2	160	141	100
COP (physical) *3	95	91	100
Ozone Depletion Potential (ODP)	0	0	0.055
Global Warming Potential (GWP) *4	675	2090	1810
Inflammability *5	Slightly Inflammable (A2L)	Non-inflammable (A1)	Non-inflammable (A1)
Toxicity	None	None	None

*1 : Physical property of temperature condition 50°C

*2 : Relative value of temperature condition 0/50°C, providing R22=100

*3 : Te/Tc/SC/SH=5/50/3/0°C

*4 : GWP=Global Warming Potential, each figure is based on “4th IPCC4 Report”

*5 : Based on ANSI / ASHRAE std. 34-2010

2. Characteristic of Pressure

As shown in Table 2, R32 does not have much difference in vapor pressure at the same refrigerant temperature comparing to R410A, but comparing to R22, it is higher at 1.6 times more. Thus, the same as in case of R410A, it is necessary to do installation and service using high-pressure tools and components.

Table 2. Saturated vapor pressure comparison table

(Unit: MPa)

Temperature	Refrigerant		
	R32	R410A	R22
-20	0.30	0.30	0.14
0	0.71	0.70	0.40
20	1.37	1.35	0.81
40	2.38	2.32	1.43
60	3.84	3.73	2.33
65	4.29	4.17	2.60

Reference : Thermal properties table of Japan Society of Refrigerating and Air Conditioning Engineers (60, 65°C)
NIST REFPROP V8.0 (-20 ~ 40°C)

13.3 Refrigerant piping installation • Tools used in services

13.3.1 Required Tools

R32 refrigerant air conditioners use the common parts as R410A air conditioners for two-way valves and three-way valves (diameters of service ports); thus, they maintain commonality in the maintenance of the compressive strength, the size of pipe flaring, and the size of flare nuts as R410A. Therefore, for refrigerant pipe installation and services, you can use tools for R410A.

However, mixing of refrigerants is not allowed, so that you have to separate the cylinders for the recovery of refrigerants.

Tools used for installation • relocation • replacement of air conditioning units

Works	R32	R410A	R22
Flaring	Flare tools for R410A (clutch type)		Flare tools for R22 (clutch type)
Connection of pipes	Torque wrench (diameter 1/4 3/8)		
	Torque wrench (diameter 1/2 5/8) *1		Toque wrench (diameter 1/2 5/8)
Manifold gauge charging hose	R32 & R410A Common (As at November 2013)		R22 Only
Air purging	Vacuum pump + Reducer / expander		Vacuum pump
Gas leakage test	Detection liquid or soup water, HFC detector		

*1. Nut diameters of 1/2 5/8, the size of torque wrench common with R410A

For other installation, you can use general tools such as screw drivers (+, -), metal saws, electric drills, long-nose pliers, hole core drills ($\phi 70$ or $\phi 65$), linen tape, levels, temperature gauges, clamp meters, electric knives, nippers, pipe cutters, reamers or scrapers, spring benders, (diameters 1/4 3/8 1/2 5/8), monkey wrenches, fixing wrenches (17 or 12 mm), feeler gauges, hexagon wrenches (4 mm), testers, megohm testers, etc.

Tools used for services

Works	R32	R410A	R22
Insertion of refrigerant	Digital scale for refrigerant charging, refrigerant cylinders, cylinder adopters and packing *a		
Recovery of refrigerant	Refrigerant recovery devices, refrigerant cylinders, manifold gauges, charging hoses *b		

*a. Use cylinder for each refrigerant, cylinder adopter and packing.

*b. Use refrigerant recovery cylinder separately for each refrigerant (**no mixture of refrigerant allowed**). Please be aware that there are some refrigerant collection devices which do not have self-certification.

13.3.2 Tools for R32 (common with R410A)

1. Flare gauges

Use flare gauges when you perform flaring with flare tools (crutch type). Flare gauges are used to set the pipe ends at 0.5 ~ 1.5 mm from clump bars of flare tools.

Flare gauges



2. Flare tools (clutch type)

Flare tools have larger holes of clump bars in order to set the pipe end at 0 ~ 0.5 mm, and have stronger springs inside to ensure solid flaring torques. These flare tools can be used commonly for R22.


Flare tools (clutch type)



3. Torque wrenches (diameters 1/2, 5/8)

In order to strengthen the compressive strength, the diameters of wrenches change depending on the flare nut sizes.

Torque wrenches



Differences in torque wrenches

	R32 (common R410A)	R22
1/2 (diameter × torque)	26 mm × 55 N•m (550 kgf•cm)	24 mm × 55 N•m (550 kgf•cm)
5/8 (diameter × torque)	29 mm × 65 N•m (650 kgf•cm)	27 mm × 65 N•m (650 kgf•cm)

4. Manifold gauges

R22 gauges cannot be used because of the high pressures.

Each port of manifold has different shapes in order to prevent inserting wrong refrigerant.

*However, the port shape for R410A and R32 is the same; therefore, attention need to be paid not to insert wrong refrigerant.

Differences in high/low pressure gauges

	R32 (common R410A)	R22
High pressure gauges (red)	-0.1 ~ 5.3 MPa -76 cmHg ~ 53 kgf / cm ²	-76 cmHg ~ 35 kgf / cm ²
Low pressure gauges (blue)	-0.1 ~ 3.8 MPa -76 cmHg ~ 38 kgf / cm ²	-76 cmHg ~ 17 kgf / cm ²

Difference in manifold port sizes

	R32 (common R410A)	R22
Port sizes	1/2 UNF20	7/16 UNF20

5. Charging hoses

The pressure resistance of charge hoses is increased. At the same time, the material is changed to HFC resistant, and the size of each manifold adopter is changed, as the port size of manifold gauge itself. Further, some hoses are with anti-gas pressure backflow valves placed near the adopters. (hoses with the valves recommended)

Manifold gauges / Charging hoses



Differences in charging hoses


		R32 (common R410A)	R22
Pressure Resistance	Normal operation pressure	5.1 MPa (52 kgf / cm ²)	3.4 MPa (35 kgf / cm ²)
	Burst pressure	27.4 MPa (280 kgf / cm ²)	17.2 MPa (175 kgf / cm ²)
Material		HNBR rubber Internal nylon coating	NBR rubber

6. Vacuum pump and Vacuum pump adopter


When using a vacuum pump, it is necessary to set a solenoid valve in order to prevent backflow of vacuum pump oil into the charge hoses, and use a vacuum pump with oil backflow prevention function, or use the vacuum pump with vacuum pump adopter.

If vacuum pump oil (mineral oil-based) mixes with R410A (R32), it may cause damage to the machine.

Vacuum pump



Vacuum pump adopter




7. HFC refrigerant_Electric gas leakage tester
R32 refrigerant is often used for other mixed refrigerant (R410A, R404A, R407C etc.). Therefore, the usage of existing HFC detectors is possible, but in order to detect more accurately, we recommend to use detectors specially set and adjusted for R32 detection.

HFC refrigerant_Electric gas leakage tester



8. Digital scale for refrigerant charging
R32 and R410A have high pressure level and their evaporation speed is high. Thus, if you recover the refrigerant by cylinder charging method, the refrigerant evaporates within the weighing scale glass, which makes reading the scale difficult, rather than liquidating the refrigerant into the cylinder. (Charging cylinders for R22 have different pressure resistance, scale, connection port size; therefore, they are not usable) At the same time, the digital scale for refrigerant charging is strengthened by receiving the weight of the refrigerant cylinders with four pillars at the corners. The connection ports of charging hoses have two separate ports for R22 (7/16 UNF20) and R32/R410A (1/2 UNF20) therefore, they can be used for the insertion of the existing refrigerants.

Digital scale for refrigerant charging




9. Refrigerant cylinders
Refrigerant cylinders for R410A are painted in pink, and the ones for R32 are painted in other colors that might subject to change according to the international standards. R32 is a single refrigerant, so that both liquid and gas insertion are possible. Additional charging is also possible. (R410A is a mixed refrigerant, so only liquid insertion is possible)

Refrigerant cylinders



10. Connection ports of refrigerant cylinders and packing
Charging ports which fit to the charging hose connection port size (1/2 UNF20) is needed. At the same time, the packing has to be of HFC resistant materials.


Connection ports and packing



11. Tools used for refrigerant piping installations and services

	Tools for R410A	Common with R32	Possibility of usage for R22
1.	Pipe cutters, reamers or scrapers	○	○
2.	Flare tools (clutch type)	○	○
3.	Torque wrench (1/4, 3/8)	○	○
4.	Torque wrench (1/2, 5/8)	○	×
5.	Manifold gauges • charging hoses	○	×
6.	Vacuum pumps, vacuum pump adapters	○ Connection 5/16	○ Connection 1/4
7.	Electric gas leakage testers for HFC *1	○	△
8.	Digital scale for refrigerant charging	○	○
9.	HCF recovery devices (connection port 5/16) *2	○ Connection 5/16	○ Connection 1/4
10.	Refrigerant cylinders (pressure resistant: FC3)	Same specs ×	×
11.	Refrigerant cylinders (pink)	Other (colors that might subject to change according to the international standards).	×
12.	Refrigerant cylinder connection ports and packing	○	×
13.	Allen wrench (4 mm) Electric knives	○	○
*1	Those testers only for HCFC22 (R22), but not for HCF32 (R32) and HCF410A (R410A) cannot be for common use.		
*2	Recovery devices which are self-certified for each HCF type can be used.		
	[Knowledge for the common usage of tools for R410A & R32] • R410A and R32 machines use different compressor oils. • If unregulated compressor oil gets mixed into, it may cause damage to the machine function. • Careful pump down will ensure the recovery of compressor oil, and it will minimize the remaining amount of the oil in the manifold gauge and charging hose. • If you only perform the recovery of refrigerant and not be able to perform pump down, <u>you have to dispose the compressor oil in the charging hose.</u>		
	[Precaution of repairing refrigerant cycle] • In the brazing, open 2-way and 3-way valves, and make sure the refrigerant is completely recovered back and not remaining the system. • When repairing outside, make sure no refrigerant is in the air, ensure good air flow, and perform the brazing.		
	[Inserting wrong refrigerant] • It may cause “not cooling” and “not heating” customer claims because each component (expansion valve, compressor, PCB) of the refrigeration cycle is specially adjusted for R32. • At the same time, it is not subject to product warranty, if wrong refrigerant was inserted into the system.		

13.4 New installation, Relocation, Repairing of Refrigerant Cycle System The Procedures



13.5 Piping installation of R32

13.5.1 Pipe materials used and flaring

Copper pipes are used for refrigerant piping. Pipes which comply with JIS Regulations need to be used. Room air conditioners which use R410A and R32 have higher pressure; thus, using pipes which comply with the Regulations is important.

The pipe thickness is regulated by revised JIS B 8607 “Flaring and brazing fittings for refrigerant” and the pipe thickness for R410A, R32 is shown in the table.

Pipe thickness

O and OL materials		Thickness (mm)		
Diameter	Diameter (mm)	R410A	R32	R22
1/4	6.35	0.80		
3/8	9.52	0.80		
1/2	12.70	0.80		
5/8	15.88	1.00		

Caution

- For connection piping, use copper phosphate seamless pipes (1220T) as regulated in “JIS H 3300” and the pipe thickness is 0.8 mm.
- In the market, there are some pipes of 0.7 mm thickness, but do not use these pipes (0.8 mm thickness has to be strictly followed).
- It is recommended to use pipes whose adhesion amount of oil is at or less than 40 mg / 10 m. At the same time, do not use pipes with dent, de-shape, and color change (especially inside).

13.5.2 Processing and connection of pipes

For refrigerant pipe installation, be aware of moisture and dirt do not get into the pipes, and make sure of no refrigerant leakage.


◎ The procedure of flaring and precautions

- Cutting of pipes : use pipe cutter and cut the pipe slowly not to de-shape the pipe.
- Removal of burrs on the edge of pipe (reamer or scraper)
If the condition of pipe edge after the deburring is no good or if burrs attaches on the flaring, it may cause refrigerant leakage. Turn the pipe end down and perform deburring carefully.
- Insert the flare nut (use the nut which is a part of the CZ parts)
- Flaring

Ensure the cleanliness of clump bar and pipe, and perform flaring carefully.

Use the existing flare tools or flare tools for R410A. Be aware that the sizes and dimensions of flaring is different in each flaring tool. If you use the existing flaring tools, use flaring gauge to measure the length of the flaring part.

Piping size (mm)	Dimensions “a” (mm) R22			Dimensions “a” (mm) R410A/R32		
	Flare tools		Flare tools for R410A	Flare tools		Flare tools for R410A
	Clutch type	Wing nut type	Clutch type	Clutch type	Wing nut type	Clutch type
6.35 (1/4")	0.5 ~ 1.0	1.0 ~ 1.5	0 ~ 0.5	1.0 ~ 1.5	1.5 ~ 2.0	0 ~ 0.5
9.52 (3/8")	0.5 ~ 1.0	1.0 ~ 1.5	0 ~ 0.5	1.0 ~ 1.5	1.5 ~ 2.0	0 ~ 0.5
12.70 (1/2")	0.5 ~ 1.0	1.5 ~ 2.0	0 ~ 0.5	1.0 ~ 1.5	2.0 ~ 2.5	0 ~ 0.5
15.88 (5/8")	0.5 ~ 1.0	1.5 ~ 2.0	0 ~ 0.5	1.0 ~ 1.5	2.0 ~ 2.5	0 ~ 0.5




Nut outer diameter (mm)	
R22	R410A R32
17	17
22	22
24	26
27	29

13.6 Installation, Relocation, and Service

13.6.1 Air purge and gas leak test for new installation (using new refrigerant pipes) using vacuum pump


(From the point of view of global environment protection, do not release CFCs into the atmosphere during installation work)

1. Connect the charging hose of manifold gauge to the service port of 3-way valve (pushing insect pin).
2. Fully open the handle Lo of manifold gauge and operate vacuum pump.
(If the needle of the low-pressure gauge reaches the vacuum immediately, check 1 procedure again)
3. Perform vacuuming 15 minutes or more, and make sure low pressure gauge reaches to -0.1 MPa (-76cmHg).
When the vacuuming completes, fully open the handle Lo of manifold gauge and stop the operation of vacuum pump, and leave it for 1 ~ 2 minutes. Then, remove the connection side of the charging hose of vacuum pump adaptor after checking the needle of manifold gauge does not turn back.
4. Open the stem of 2-way valve to 90° in anti-clock wise, and close the 2-way valve after 10 seconds, and perform gas leakage test.
5. Remove the charge hose from the service port of 3-way valve, and open the stems of 2-way and 3-way valves (open the valves to anti-clock wise carefully, do not use full strength to open)
6. Tighten the service port cap with torque wrench $18\text{ N}\cdot\text{m}$ ($1.8\text{ kgf}\cdot\text{m}$)
Tighten the caps of 2-way and 3-way valves with torque wrench $18\text{ N}\cdot\text{m}$ ($1.8\text{ kgf}\cdot\text{m}$)
7. After the tightening of each cap, check gas leakage around the cap.



13.6.2 Process of refrigerant recovery

1. Connect the center charging hose of manifold gauge to the in-let side of recovery device.
2. Connect the valves of the discharge side of recovery device and liquid side of refrigerant cylinder with red hose (charging hose).
3. Connect the yellow float switch cable of the recovery device to the refrigerant cylinder.
4. Open the low pressure side valve of manifold gauge.
5. Slightly loosen the charging hose of in-let connecting side of recovery device and perform air purge.
6. Open the liquid valve of refrigerant cylinder and slightly loosen the charging hose in discharging side of recovery device, and perform air purge (the recovery cylinder needs slight inside pressure).
7. Insert electric plug of recovery device into electrical outlet (the fan operation starts).
8. Turn the valve 1 and 2 of recovery device to pressure equalization point.
9. After a few seconds, turn back the valve 1 and 2 to the original position.
10. Turn the switch of the recovery device to "ON". (the compressor operation starts)
11. When the low pressure of manifold gauge is close to "0", close the low pressure side valve, turn "OFF" the recovery device switch.
12. Remove the center charging hose of manifold gauge from the recovery device.



13.6.3 Relocation

1. Removing the air conditioning unit

a) Recovery of outdoor unit refrigerant by pumping down

Press “forced cooling button” (as a general rule, since 1998 the name of cooling testing button is changed, and this name is unified within the air conditioning industry), and then you are able to start cooling operation in which the room temperature is low, and you can recover the refrigerant from the outdoor unit.

1. Check the valve stems of two-way and three-way valves are open by being turned to anti-clockwise (Remove the caps, and confirm the bars are fully open. Use hexagon wrench <4 mm> to open and close the valves).
2. Press the “Emergency Operation” button of the indoor units for five seconds and release [Forced cooling operation] (for old models, press “forced cooling” button). Then, operate the air conditioning unit for about 10 minutes.
3. Turn the stem of the two-way valve to the clock-wise and close the valve.
4. After about 2 ~ 3 minutes, turn the stem of the three-way valve quickly to the clock-wise, and stop the operation.

Caution: In the pump down operation, stop the compressor before removing the refrigerant pipes.

If you do not stop the compressor operation, and if the valve is open and remove the refrigerant pipes, the air may be sucked into the system and causes extreme high temperature in the refrigerant cycle. This may result in rupture or injury, etc.

5. Attach and tighten the caps of two-way and three-way valves with torque wrench.
6. Remove the connecting pipes (liquid side and gas side).

b) Removal of indoor and outdoor units

1. Remove the connecting pipes and wires between the indoor and outdoor units.
2. Attach capping flare nuts on the edges of the pipes, connecting the indoor and outdoor units, in order to prevent dust and moisture get into the pipes.
3. Remove the indoor and outdoor units.

2. Unit installation

Use new refrigerant pipes for the installation, and perform air purging using vacuum pump and gas leakage testing stated in 14.5.1.

13.6.4 Replacement of air conditioning units and evacuation (when re-using the existing pipes)

When replacing the air conditioning units, you might use the existing pipes, but it is recommended to perform flaring again. In case of unit replacement, even if the unit is new refrigerant air conditioner, if the refrigerant oil is different, it may cause problem. Further, when re-using the existing refrigerant pipes, it is recommended to evacuate the pipes as much as possible, due to the reason that much refrigerant oil may be attached on the surface of the pipes. If the pipes are used without evacuation, the remaining refrigerant oil may cause under-performance and abnormal refrigerant cycle caused by non-compatibility of those oils.

13.6.5 Inter-changeability of refrigerant

Do not operate air conditioning units inserting wrong (or mixed) refrigerant (R22, R410A, R32). It may cause malfunction of the units, and at the same time, may cause serious incident such as rupture of the refrigerant cycle.

13.6.6 Re-insertion of refrigerant in service

When re-insertion is needed, follow the procedures to ensure the insertion of new refrigerant at correct amount.

1. Attach charging hose (blue) to the service port of the outdoor unit.
2. Attach charging hose (red) to the vacuum pump. Fully open the 2-way and 3-way valves.
3. Place the refrigerant cylinder on the digital scale for refrigerant charging and connect the charge hose (yellow) to the connection port of the vacuum pump and the digital scale. Leave the cylinder valve fully open.
4. Fully open the handles Lo and Hi of the manifold gauge, and switch on the vacuum pump, and then perform evacuation for at or more than one hour.
5. Confirm the compound gauge of -0.1 MPa (-76cmHg) and fully open the handles of Lo and Hi, and switch off the vacuum pump. Leave it for about 1 ~ 2 minutes and confirm the needle of the compound gauge does not turn back.

Refer to the picture below to follow the procedures below.


6. Remove the charging hose (red) of the manifold gauge from the vacuum pump adaptor.
7. After adjusting the digital scale to zero, open the cylinder valve and the valve Lo of the manifold gauge, and insert the refrigerant.
8. If it is not possible to insert the refrigerant at regulated amount at once, operate the cooling mode and gradually insert the refrigerant (recommended amount approx. 150 g / 1 time)

*Do not insert much refrigerant at once.

9. Close the open/close valve and insert the refrigerant in the charging hose to the outdoor unit.
*Perform this procedure during operating cooling operation. Close the stem of the two-way valve, and when the pressure of the manifold gauge becomes zero (0), quickly remove the charging hose (blue). Immediately open the 2-way valve, and stop the cooling operation.

10. Final checking • • • Confirm the 2-way and 3-way valves are fully open.

Attach the caps of the service port and control valve, and then check the gas leakage around the caps.



13.7 Repairing of refrigerant cycle / Brazing point


13.7.1 Preparation for repairing of refrigerant cycle / brazing

Brazing which is a technique needed for repairing refrigerant cycle requires advanced technique and experience, and this brazing procedure can only be performed by the workers who completed “Gas Welding Skill Training” regulated by the Occupational Safety and Health Act, and went through the training programs of refrigerant operations. Dismantling and re-connecting (assembling) refrigerant system requires working space, and the space has to ensure good air flow and fire prevention (water bucket and fire extinguisher). Moreover, the worker has to ensure the wearing of goggles, grabs, safety shoes, and long sleeve shirts, and be aware of work safety and attempt to prevent secondary defect (quality assurance of products). For brazing the indoor / outdoor unit structural components (heat exchangers, compressors, expansion valves, four-way valve blocks), after the recovery of all refrigerant, confirm that no refrigerant remains in the system, and fully open the 2-way and 3-way valves. When the brazing is conducted outside, check and make sure no refrigerant is contained in the air (be careful with vaporized refrigerant). Furthermore, protect the compressor terminal with metal plates, and heat but use wet clothes to cool down (releasing the heat) the expansion valves, and four way valves (prevent destruction of parts). In brazing, it is important to pour the brazing material without melting the base metal based on capillary action principle. In case of holes and oxidizing caused by overheating, do not perform re-brazing or alteration but replace the parts.

13.7.2 Adjustment of vacuum pump pressure

1. Cylinder with adjustment handle

1. Check and confirm the adjustment handle of the 1st pressure adjuster is loosen (anticlockwise). If cylinder valve is opened when the 1st gauge pressure adjust handle is closed, the 2nd gauge might get broken.



2. Open the cylinder valve, and check the remaining amount with the first side pressure gauge.
3. Check the pressure of 2nd gauge and turn the adjustment handle to clock-wise direction to adjust the pressure.
 - ◎ Oxygen 2nd side gauge pressure 0.5 MPa (5.0 kgf / cm²)
 - ◎ Propane 2nd side gauge pressure 0.05 MPa (0.5 kgf / cm²)


2. Cylinder without adjustment valve

2nd side gauge pressure is adjusted by the adjuster.

Check the both side valves of the torch and open the cylinder valve to check the remaining refrigerant in the cylinder.

Caution: Do not attach oil component on the connection port of the adjuster.

Especially, use an oxygen cylinder adjuster which is no oil substance type. Do not dismantle or repair the adjuster and pressure gauge.




13.7.3 Checking of gas provision

Checking there is no fire around the torch, and then confirm the provision of gas.

1. Slightly open the “propane valve” of the torch, and make sure the gas comes out from the torch crater and then close the “propane valve”.
 2. Slightly open the “oxygen valve” of the torch and make sure the gas comes out from the torch crater and then close the “oxygen valve”.
- Check there is no gas leakage around the hose connection.

13.7.4 Adjustment of flame

1. Slightly open the “propane valve” of the torch and lit with spark lighter.
This moment, the flame is only by propane and the color is red.
 2. Gradually open the “oxygen valve” of the torch to mix oxygen, and adjust the amount of propane and oxygen with the valve to make the flame suitable for brazing work.
- If the white core flame splits into two, the torch crater might be clogged. In this case, remove the crater from the torch and check.




13.7.5 Types of flame

Types of flame change based on the proportion of propane and oxygen.

[Neutral Flame]

Perform brazing with this flame

(This is a flame when oxygen and propane are mixed at proper proportion, and has lesser effect on the brazed metals)




[Carbide Flame]

When propane is excessive, the flame has white color flame in between the white core flame and outer flame.

(This is due to the lack of oxygen and the proportion of unburned propane is excessive.


The black carbon created during the brazing work may contaminate the surface of the brazed metal).



[Oxidizing Flame]

Oxygen is more compared to the neutral flame. Although the flame size is small, this has the highest flame heat.

However, due to the excessive oxygen contained in the flame, the brazing point gets oxidized. (This flame may cause holes, due to the high heat. The pipe may get melt)



13.7.6 Closing the flame

[In case of short break]

1. Close the "propane valve" of the torch.
2. Close the "oxygen valve" of the torch.

[In case of finishing work]

1. As above, close the flame following the procedure of "In case of short break".
 2. Completely close the valves of oxygen and propane cylinders.
 3. Release the remaining gas inside the hose by opening the "oxygen valve" and "propane valve" of the torch.
- Confirm the 1st and 2nd side gauge pressures of "oxygen" and "propane" cylinder pressure adopter are "zero".

13.7.7 Selection of brazing material

Use BAg brazing material (silver solder) to increase the welding performance.

Category	JIS Standard Number	Composition of ingredients (%)						Temperature (°C)			Tensile strength (Reference)		Characteristics and applications
		Ag	Cu	Zu	Cd	Ni	P	Solidus	Liquidus	Brazing temp	Kgf/cm ²	Base material	
BAg	BAg • 1A	49.0 ~ 51.0	14.5 ~ 16.5	14.5 ~ 18.5	17.0 ~ 19.0	—	—	approx. 625	approx. 635	635 ~ 760	45.5	S20C	Liquidity is good at low temperature, it is preferable to a small junction of the gap in the universal form.
	BAg • 1	44.0 ~ 56.0	14.0 ~ 16.0	14.0 ~ 18.0	23.0 ~ 25.0	—	—	approx. 605	approx. 620	620 ~ 760	45.5	S20C	It has similar performance to the BAg • 1A, and suitable for every base material except the light weight metal.
	BAg • 2	34.0 ~ 36.0	25.0 ~ 27.0	19.0 ~ 23.0	17.0 ~ 19.0	—	—	approx. 605	approx. 700	700 ~ 845	45.5	S20C	It is a brazing filler metal in universal form, suitable for a slightly larger gap junction.
	BAg • 3	48.0 ~ 51.0	14.5 ~ 16.5	13.5 ~ 17.5	15.0 ~ 17.0	2.5 ~ 3.5	—	approx. 630	approx. 690	690 ~ 815	35 ~ 70	SS ~ SUS	It has good corrosion resistance in stainless steel-based brazing, suitable for brazing tungsten carbide, aluminum bronze and copper.
BCuP	BCuP-2	—	remain	—	—	—	6.8 ~ 7.5	approx. 710	approx. 785	690 ~ 815	21 ~ 24.5	Cu	Good liquidity, suitable for brazing copper tube.
	BCuP-3	4.8 ~ 5.2	remain	—	—	—	5.8 ~ 6.7	approx. 645	approx. 815	720 ~ 815	21 ~ 24.5	Cu	Suitable for brazing when the joint spacing is not constant
	BCuP-5	14.5 ~ 15.5	remain	—	—	—	4.8 ~ 5.3	approx. 645	approx. 800	705 ~ 815	21 ~ 24.5	Cu	When brazing of copper and copper, it is used without a flux, but not possible for brazing basic materials

Caution

BCuP (phosphorus copper wax) is easy to react with sulfur, and makes a brittle compound water soluble, and causes gas leakage. In hot spring areas, use other brazing materials or paint the surface for protection.

13.7.8 Need of flux

Use flux to protect the base materials.




1. Remove impurity and oxide film on the metal base, and improve the flow of the brazing material.
2. Prevent oxidation of the metal surface in brazing.
3. Reduce the surface tension of the brazing material.

13.7.9 Need of nitrogen gas

In order to prevent oxidation in the pipe, perform the brazing operation in nitrogen gas flow. Flow rate 0.05 m³ / h, or pressure reducing valve at 0.02 MPa (0.2kgf / cm²) below.


13.7.10 Checking of brazing (insert) points

1. No impurity on the brazing point
If dirt or oil is attached on the brazing point, the brazing filler metal does not reach to junction, and it may cause poor welding.
2. Adequate gap space in the brazing point
The advantage of capillary current situation is used in brazing. If the gap space is too large, this phenomenon may not occur and it may cause poor welding because brazing filler metal does not flow to join the front part.
3. Appropriate size for insertion
The guideline for pipe insertion dimensions is to three times the diameter of the base material, but you need to decide the insertion size in consideration of the clogging of the brazing material. Generally, for thin pipes, you need to increase the insert size, and for thick pipe vice versa.
4. Brazing material to flow from top to bottom
Brazing filler metal will easily flow to the connecting portion by capillary action. Further, by bending the brazing portion of [dryer side] of the capillary tube at 15 mm from the tube top to the angle of about 120°, you can prevent the damage of dryer inside and the clogging of brazing material caused by the excessive insertion of capillary tube.



13.7.11 Brazing and heating

1. Place the flame to a pipe which has more heat capacity in order to let the brazing material melt by the pipe heat. Heat the pipe up to the melting temperature of the brazing material, but when it is overheating, assess the temperature by pipe color in order not to melt the pipe.



The pre-heating is to heat the base material until the melting temperature, and requires certain training to distinguish the color of the heated base material in order not to melt the material.

The color and temperature of copper tube

- Becoming red color 480°C
- Dull red 650°C
- Cherish red 760°C
- Brightening cherish red 870°C


(Reference)

Melting temperature of copper ••••••• Approx. 1083°C

Maximum temperature obtained in propane and oxygen ••••••• Approx. 1083°C

The important point is to heat the bonding part uniformly within a short period of time until reaching to the brazing temperature in the following manner.

2. Apply the flame on to the side with better heat transmission. If the pipe thickness is consistent, by heating like 30% iron and 70% copper, the copper pipe inside reaches to brazing temperature.
Iron pipes have low heat transmission and only the part the flame is applied get high temperature, and this causes oxidization of the pipe. The flow of the brazing filler is affected negatively.
3. Apply the flame on to the side of larger heat capacity.
When brazing a thin tubes such as capillary tube and dryer, etc., caution has to be taken to apply the flame to the dryer side (thick pipe side), in order to prevent burn out by the heat.
4. When brazing the compressor connection pipes (suction and discharge), remove the sound insulation plate and the fan, and place the compressor stand vertically (to prevent the leakage of compressor refrigerating machine oil), and apply the flame from the compressor body side.



13.7.12 Terminologies of brazing

Pin holes → Small holes are generated on the surface of the brazing metal.

Wet temperature → Liquidus temperature at which the brazing material starts flowing out by heating, generally it is the liquidus-line temperature.

Blow holes → Hollows made by gas in the brazing material of brazing portion (gas reservoirs).

Pits → As a result of blow holes, small dents generated on the outside surface of welding.

Voids → The brazing material does not reach completely to the brazing part. It cannot be identified from outside.

13.8 <Reference> Analysis method for no error code, no cooling / no warming

13.8.1 Preparation for appropriate diagnosis

In order to obtain appropriate operation characteristics, minimum 15 minutes or more operation time [testing operation (rated operation)] is required.


1. Method of rated operation (rated operation)

For the models which have two buttons of "emergency operation and forced cooling operation", press forced cooling button once. For the models which have only emergency operation button, press the button once for 5 seconds and when hear "beep" sound, release the button. Then, cooling operation starts.

2. Checking the mal-functions of indoor / outdoor units

- 1) Any obstacles against heat release and air suction? (short circuit)
(Forget to remove the outdoor unit cover or fallen leaves blocking the outdoor unit)
- 2) Are the indoor unit air filters clean? (obstructing heat suction)
- 3) Is the setting temperature on the remote controller correct? (is the setting temperature set at lower/higher than the room temperature?)

13.8.2 Understanding and verification of refrigerant cycle



1. Measuring temperature
 - 1) Indoor unit suction temperature, release temperature, temperature difference, → Measure by thermometer
 - 2) 2-way valve pipe temperature in cooling mode is low temperature (benchmark : 5 ~ 10°C), in heating mode is medium temperature (benchmark : 25 ~ 35°C).
 - 3) 3-way valve pipe temperature in cooling mode is low temperature (benchmark : 7 ~ 15°C) in heating mode is high temperature (benchmark : 38 ~ 50°C).
2. Measuring electric current
 - Measuring electric current in operation → check by clamp meter (refer to table of technical characteristic guideline)
3. Measuring pressure
 - Measuring gas pressure → check the pressure by manifold gauge (refer to table of technical characteristic guideline)
4. Any sound from the expansion valve?
(when starting the operation and the outdoor unit is turned on, the expansion valve is re-set, check if there is any edged sound or clack sound)

13.8.3 Guidance for diagnosis of refrigerant cycle

Comparison with normal operation	Cooling mode	
	High	Low
Refrigerant pressure	Excess insertion of refrigerant	Clogged capillary, expansion valve malfunction
	Heat releasing obstruction	Clog by moisture
	Dirty condenser, attachment of impurity	Lack of refrigerant gas
	Compressor malfunction	
Operation electric current	Excess insertion of refrigerant	Lack of refrigerant gas
	Heat releasing obstruction	Compressor malfunction
	Dirty condenser, impurity	Mixture of air
		(Insufficient evacuation)
2-way valve temperature	Excess insertion of refrigerant	Clogged capillary, expansion valve malfunction
	Compressor malfunction	Lack of refrigerant gas
3-way valve temperature	Lack of refrigerant gas • Compressor malfunction	Excess insertion of refrigerant
	Clogged capillary, expansion valve malfunction	

Suction temperature & Release air temperature	Temperature difference at or less than 8°C in cooling operation • • • Causes		
	• Heat releasing obstruction	• Dirty condenser	• Attachment of impurity
	• Lack of refrigerant gas	• Excess insertion of refrigerant	
	• Mixture of air	• Mixture of moisture	
	• Clogged capillary	• Expansion valve malfunction	• Compressor malfunction

- ◎ Above all are based on the condition that the installation work is properly performed (no issues in indoor / outdoor pipe connections, etc.)


14. Operation and Control

14.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal setting temperature and intake air temperature.

14.1.1 Internal Setting Temperature

Once the operation starts, remote control setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the air conditioner settings and the operation environment. The final shifted value will be used as internal setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.



14.1.2 Cooling Operation

14.1.2.1 Thermostat control

- Compressor is OFF when Intake Air Temperature - Internal Setting Temperature < -2.0°C continue for 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature - Internal Setting Temperature > Compressor OFF point.

14.1.3 Soft Dry Operation

14.1.3.1 Thermostat control

- Compressor is OFF when Intake Air Temperature - Internal Setting Temperature < -2.0°C continue for 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature - Internal Setting Temperature > Compressor OFF point.


14.1.4 Heating Operation

14.1.4.1 Thermostat control


- Compressor is OFF when Intake Air Temperature - Internal Setting Temperature $> +2.0^{\circ}\text{C}$.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature - Internal Setting Temperature $<$ Compressor OFF point.

14.1.5 Automatic Operation

- This mode can be set using remote control and the operation is decided by remote control setting temperature, remote control operation mode and indoor intake air temperature.
- During operation mode judgment, indoor fan motor (with speed of Lo-) is running for 30 seconds to detect the indoor intake air temperature.
- Every 10 minutes, the indoor temperature is judged.
- For the 1st judgment
 - If indoor intake temperature - remote control setting temperature $\geq 2.0^{\circ}\text{C}$, COOL mode is decided.
 - If $-2.0^{\circ}\text{C} \leq$ indoor intake temperature - remote control setting temperature $< 2.0^{\circ}\text{C}$, DRY mode is decided.
 - If indoor intake temperature - remote control setting temperature $< -2.0^{\circ}\text{C}$, HEAT mode is decided.



- For the 2nd judgment onwards
 - If indoor intake temperature - remote control setting temperature $\geq 3.0^{\circ}\text{C}$, if previous operate in DRY mode, then continue in DRY mode. otherwise COOL mode is decided.
 - If $-2.0^{\circ}\text{C} \leq$ indoor intake temperature - remote control setting temperature $< 3.0^{\circ}\text{C}$, maintain with previous mode.
 - If indoor intake temperature - remote control setting temperature $< -2.0^{\circ}\text{C}$, HEAT mode is decided.



14.1.6 Fan Operation

- Fan operation is used to circulate air in the room.
- During operation, indoor fan run continuously but outdoor fan and compressor stop.
- Temperature setting is not applicable.

14.1.7 Indoor Fan Motor Operation

A. Basic Rotation Speed (rpm)

i. Manual Fan Speed

[Cooling, Dry]

- Fan motor's number of rotation is determined according to remote control setting.

Remote Control	O	O	O	O	O
Tab (rpm)	Hi	Me+	Me	Me-	Lo

[Heating]


- Fan motor's number of rotation is determined according to remote control setting.

Remote Control	O	O	O	O	O
Tab (rpm)	Shi	Me+	Me	Me-	Lo

ii. Auto Fan Speed


[Cooling, Dry]

- According to room temperature and setting temperature, indoor fan speed is determined automatically.
- The indoor fan will operate according to pattern below.



[Heating]

- According to indoor pipe temperature, automatic heating fan speed is determined as follows.




B. Feedback control

- Immediately after the fan motor started, feedback control is performed once every second.
- During fan motor on, if fan motor feedback ≥ 2550 rpm or < 50 rpm continue for 10 seconds, then fan motor error counter increase, fan motor is then stop and restart. If the fan motor counter becomes 7 times, then H19 - fan motor error is detected. Operation stops and cannot on back.

14.1.8 Outdoor Fan Motor Operation

It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



14.2 Quiet Operation (Cooling)

- Purpose
 - To provide quiet cooling operation compare to normal operation.
- Control condition
 - Quiet operation start condition
 - When  operation is selected.  will be shown on remote control display.
 - Quiet operation stop condition
 - Quiet is disable when fan speed is changed or Powerful is enable.
- When quiet operation is stopped, operation is shifted to normal operation with previous setting.
- When operation mode is change, quiet operation is shifted to quiet operation of the new mode.
- During quiet operation, if timer "ON" activates, quiet operation maintain.
- After OFF, when ON back, quiet operation is memorized.
- Control content
 - Fan speed is changed to QLo.

14.3 Quiet Operation (Heating)

- Purpose
 - To provide quiet heating operation compare to normal operation.
- Control condition
 - Quiet operation start condition
 - When  operation is selected.  will be shown on remote control display.
 - Quiet operation stop condition
 - Quiet is disable when fan speed is changed or Powerful is enable.
- When quiet operation is stopped, operation is shifted to normal operation with previous setting.
- When operation mode is change, quiet operation is shifted to quiet operation of the new mode.
- During quiet operation, if timer "ON" activates, quiet operation maintain.
- After OFF, when ON back, quiet operation is memorized.
- Control content
 - Fan speed is changed to QLo.

14.4 Powerful Operation

- Purpose
 - To achieve the setting temperature quickly.
- Control condition
 - Powerful operation start condition
 - When  is selected.  Will be display on remote control display.
 - Powerful operation stop condition
 - Powerful operation will be disable after 20 minutes.
 - Powerful operation will be disable when fan speed is changed and Quiet operation is enable.
- Control content
 - When powerful mode is selected, the internal setting temperature will shift lower up to 4.0°C (for Cooling) or higher up to 6.0°C (for heating) than remote control setting temperature for 20 minutes.

14.5 Weekly Timer




Weekly timer

Select this icon to delete (cancel) or change the pre-set Weekly Timer.

Press  **to confirm your selection.**

When Weekly Timer mode is selected, an icon will appear on top left of Main Screen.

*Refer to "Remote Controller buttons and display"



Do you want to edit
Weekly timer pattern?

Yes ▶ No

Select "Yes".

• If you select "No", the screen will return to the Quick Menu Screen.

Timer setup

Timer copy

• Timer setup: Select Timer setup to edit the Weekly Timer.

• Timer copy: Select to copy a timer setting.

Sun	Mon	Tue	Wed	Thu	Fri	Sat
✓	✓	✓	✓	✓	✓	✓

[Example of a Timer setup]

Select the day(s) which you wish to edit using ▲ ▼ buttons.

All 6 patterns are not set!
Do you want to edit?

Yes ◀ **No**

If all 6 patterns are not preset, this screen will be displayed.

Weekly timer		12:00, Mon				
Sun	Mon	Tue	Wed	Thu	Fri	Sat
1.	6:00am	ON	⊗	⊗	25.0°C	
2.	8:00am	ON	⊗	⊗	25.0°C	
3.	10:00am	ON	⊗	⊗	25.0°C	
①	②	③	④	⑤		

① **Select pattern "1" ~ "6".**

② **Set the hour and minutes of the Timer.**

③ **Select ON/OFF of the Timer.**

④ **Select the operation mode.**



⑤ **Set the temperature.**

Stop Condition:


- ON/OFF button is pressed.

14.6 Auto Restart Control

- 1 When the power supply is cut off during the operation of air conditioner, the compressor will re-operate within three to four minutes (there are 10 patterns between 2 minutes 58 seconds and 3 minutes 52 seconds to be selected randomly) after power supply resumes.
- 2 This control can be omitted by open the circuit of JP10 at indoor unit printed board.


14.7 HA Terminal (HAJEM-A)

- Enable digital connection from indoor unit to external devices.
- Control items:
 - 1 Start/stop input.
 - 2 Start/stop signal output.



- Condition
 - 1 1-2 (Pulse input): Unit ON/OFF condition switching with a pulse signal.
(1 pulse signal: shortage status 200~300msec)
 - 2 3-4 (Static output): 5V output during the unit ON. No output at OFF.

Example of wiring:



Note: The wire length from indoor unit to the external interface must be within 1.9 meters. The wire must be double insulation type and a ferrite core to be added to reduce noise. Proposed core spec is J0KE00000147 with Heat Shrinkage Tube.

The signal between indoor unit and the external interface must be isolated by photo-coupler of approval type (e.g: Semko, VDE etc).

14.8 Drain Pump Control

- This unit has built-in with drain pump.

Control content

- During COOL/DRY mode.
 - During COOL/DRY mode, drain pump starts 10 seconds after indoor fan motor starts.
 - The drain pump turns ON and turns OFF periodically. (ON or OFF duration depends on room temperature).
- After COOL/DRY mode, when unit turns OFF (power standby) or changes to HEAT mode.
 - The drain pump turns ON for 60 seconds immediately.
- Error judgment
 - When float switch detects ON signal continuously for 2 minutes 30 seconds, error code H21 are shown.
 - When float switch ON has operated 2 times within 20 minutes, error code H35 are shown.

14.9 Pump down Operation by CN-S

- A convenience method to activate pump down operation.
- Control start condition:
 - During power standby condition, short CN-S continuously between 1 second and 10 seconds.
- Control stop condition:
 - 480 seconds after pump down operation starts.
 - CN-S is shorted again during pump down operation.

15. Operation Control (For Multi Split Connection)

During multi split connection, indoor unit's operation controls are same with single split connection unless specified in this chapter.

15.1 Cooling operation

15.1.1 Thermostat control

- Capability supply to indoor unit is OFF (Expansion valve closed) when Intake Air Temperature — Internal setting temperature $< -2.0^{\circ}\text{C}$.
- Capability resume supply to indoor unit after waiting for 3 minutes, if the Intake Air temperature — Internal setting temperature $>$ Capability supply OFF point.

15.2 Soft Dry Operation

15.2.1 Thermostat control

- Capability supply to indoor unit is OFF (Expansion valve closed) when Intake Air Temperature — Internal setting temperature $< -3.0^{\circ}\text{C}$.
- Capability resume to indoor unit after waiting for 3 minutes, if the Intake Air temperature — Internal setting temperature $>$ Capability supply OFF point.

15.3 Heating Operation

15.3.1 Thermostat control


- Capability supply to indoor unit is OFF (Expansion valve closed) when Intake Air Temperature — Internal setting temperature $> +1.0^{\circ}\text{C}$.
- During this condition, the indoor fan is stopped if compressor is ON.
- Capability resume supply to indoor unit after waiting for 3 minutes, if the Intake Air Temperature — Internal setting temperature $<$ Capability supply OFF point.

15.3.2 Temperature Sampling Control

- Temperature sampling is controlled by outdoor unit where room temperature for all power supply ON indoor unit could be obtained.
- When capability supply to the indoor unit is OFF and the compressor is ON, the indoor fan motor is stopped. During this condition, 15 seconds after sampling signal from outdoor unit is received, the indoor fan start operation at low fan speed.
- However, within first 4 minutes of capability stopped supply to the indoor unit, even sampling signal is received, the sampling control is cancelled.

15.4 Automatic Operation

- This mode can be set using remote control and the operation is decided by remote control setting temperature, remote control operation mode, indoor intake and outdoor air temperature.
- During operation mode judgment, indoor fan motor (with speed of -Lo) and outdoor fan motor are running for 30 seconds to detect the indoor intake and outdoor air temperature. The operation mode is decided based on below chart.



- Every 180 minutes, the indoor and outdoor temperature is judge. Based on remote control setting temperature, the value of T1 will increase up to 10°C, T2 will decrease by 3°C and T3 will decrease up to 8°C.

15.5 Indoor Fan Motor Operation

15.5.1 Residual Heat Removal Control

- To prevent high pressure at indoor unit, when heating mode thermostat-off condition or power supply OFF, indoor fan continue to operate at controlled fan speed for maximum 30 seconds then stop.

15.6 Powerful Mode Operation

- When the powerful mode is selected, the internal setting temperature will shift lower up to 4.0°C for Cooling/Soft Dry or higher up to 6.0°C for heating than remote control setting temperature. This operation stops automatically after 20 minutes.

15.7 Auto Restart Control

- When the power supply is cut off during the operation of air conditioner, the compressor will re-operate between three to four minutes (10 patterns to be selected randomly) after power resume.
- During multi split connection, Indoor unit will resume previous mode, include unit standby mode.

16. Protection Control

16.1 Protection Control for All Operations

16.1.1 Restart Control (Time Delay Safety Control)


- The Compressor will not turn on within 3 minutes from the moment operation stops, although the unit is turned on again by pressing OFF/ON button at remote control within this period.
- This control is not applicable if the power supply is cut off and on again.
- This phenomenon is to balance the pressure inside the refrigerant cycle.

16.1.2 Total Running Current

- 1 When the outdoor unit total running current (AC) exceeds X value, the frequency instructed for compressor operation will be decreased.
- 2 If the running current does not exceed X value for 5 seconds, the frequency instructed will be increased.
- 3 However, if total outdoor unit running current exceeds Y value, compressor will be stopped immediately for 3 minutes.

Model	Z25CD3EAW		Z35CD3EAW		Z50CD3EAW		Z60CD3EAW	
Operation Mode	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)
Cooling / Soft Dry (A)	4.53	14.66	6.25	14.66	10.68	14.66	12.40	14.66
Cooling / Soft Dry (B)	3.98		5.79		10.14		11.95	
Cooling / Soft Dry (C)	3.98		5.79		10.14		11.95	
Heating	5.25		5.52		9.32		10.59	

- 4 The first 30 minutes of cooling operation, (A) will be applied.




16.1.3 IPM (Power transistor) Prevention Control

- Overheating Prevention Control
 - 1 When the IPM temperature rises to 120°C, compressor operation will stop immediately.
 - 2 Compressor operation restarts after 3 minutes the temperature decreases to 110°C.
 - 3 If this condition repeats continuously 4 times within 20 minutes ("F96" is indicated).
- DC Peak Current Control
 - 1 When electric current to IPM exceeds set value of 16.0 ± 2.0A (Z25/35CD3) and 30.0 ± 3.0A (Z50/60CD3), the compressor will stop operate. Then, operation will restart after 3 minutes.
 - 2 If the set value is exceeded again more than 30 seconds after the compressor starts, the operation will restart after 1 minute.
 - 3 If the set value exceeded again within 30 seconds after the compressor starts, the operation will restart after 1 minute. If this condition repeats continuously for 7 times, all indoor and outdoor relays will be cut off ("F99" is indicated).

16.1.4 Compressor Overheating Prevention Control

- Instructed frequency for compressor operation will be regulated by compressor temperature. The changes of frequency are as below.
- If compressor temperature exceeds 103°C, compressor will be stopped, occurs 4 times per 20 minutes ("F97" is indicated.)



16.1.5 Low Pressure Prevention Control (Gas Leakage Detection)

- Control start conditions
 - For 5 minutes, the compressor continuously operates and outdoor total current is between 0.75A and 0.95A (Z25/35CD3), 1.38A and 1.65A (Z50/60CD3).
 - During Cooling and Soft Dry operations:
Indoor suction temperature - indoor piping temperature is below 4°C.
 - During Heating operations :
Indoor piping temperature - indoor suction is under 5°C.
- Control contents
 - Compressor stops (and restart after 3 minutes).
 - If the conditions above happen 2 times within 20 minutes, the unit will:
 - Stop operation
 - "F91" indicated.

16.1.6 Low Frequency Protection Control 1

- When the compressor operate at frequency lower than 24 Hz continued for 20 minutes, the operation frequency will be changed to 23 Hz for 2 minutes.

16.1.7 Low Frequency Protection Control 2


- When all the below conditions comply, the compressor frequency will change to lower frequency.

Temperature, T, for:	Cooling/Soft Dry	Heating
Indoor intake air (°C)	$T < 14$ or $T \geq 30$	$T < 14$ or $T \geq 28$
Outdoor air (°C)	$T < 13$ or $T \geq 38$	$T < 4$ or $T \geq 24$
Indoor heat exchanger (°C)	$T < 30$	$T \geq 0$


16.2 Protection Control for Cooling & Soft Dry Operation

16.2.1 Outdoor Air Temperature Control

- The compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



- The compressor will be stopped to avoid compressor overloading.



16.2.2 Cooling Overload Control

- Detects the Outdoor pipe temperature and carry out below restriction/limitation (Limit the compressor Operation frequency).
- The compressor stop if outdoor pipe temperature exceeds 60°C.
- If the compressor stops 4 times in 20 minutes (F95 indicated: outdoor high pressure rise protection).

16.2.3 Freeze Prevention Control 1

- When indoor heat exchanger temperature is lower than 0°C continuously for 6 minutes, compressor will stop operating.
- Compressor will resume its operation 3 minutes after the indoor heat exchanger is higher than 5°C.
- At the same time, indoor fan speed will be higher than during its normal operation.
- If indoor heat exchanger temperature is higher than 13°C, the fan speed will return to its normal operation.

16.2.4 Freeze Prevention Control 2

- Control start conditions
 - During Cooling operation and soft dry operation
 - During thermo OFF condition, indoor intake temperature is less than 10°C or
 - Compressor stops for freeze prevention control
 - Either one of the conditions above occurs 5 times in 60 minutes.
- Control contents
 - Operation stops
 - "H99" indicated

16.2.5 Dew Prevention Control 1

- To prevent dew formation at indoor unit discharge area.
- This control will be activated if:
 - Outdoor air temperature and Indoor pipe temperature judgment by microcontroller is fulfilled.
 - When Cooling or Dry mode is operated more than 20 minutes or more.
- This control stopped if:
 - Compressor stopped.
 - Remote control setting changed (fan speed / temperature).
 - Outdoor air temperature and indoor intake temperature changed.
- Fan speed will be adjusted accordingly in this control.

16.2.6 Odor Cut Control

- To reduce the odor released from the unit.
 - Start Condition
 - AUTO FAN Speed is selected during COOL or DRY operation.
 - During freeze prevention control and timer preliminary operation, this control is not applicable.
 - Control content
 - Depends on compressor conditions:
 1. Compressor OFF → Compressor ON.
The indoor unit fan stops temporarily and then starts to blow at minimum airflow for 30 seconds.
 2. Compressor ON → Compressor OFF.
The indoor unit fan stops for 90 seconds and then blows at minimum airflow for 20 seconds.


16.3 Protection Control for Heating Operation

16.3.1 Intake Air Temperature Control

Compressor will operate at limited freq., if indoor intake air temperature is 30°C or above.


16.3.2 Outdoor Air Temperature Control

- The Max current value is regulated when the outdoor air temperature rise above 14°C in order to avoid compressor overloading.



16.3.3 Overload Protection Control

- The compressor operating frequency is regulated in accordance to indoor heat exchanger temperature as shown below.
- If the heat exchanger temperature exceeds 60°C, compressor will stop.



16.3.4 Low Temperature Compressor Oil Return Control

- In heating operation, if the outdoor temperature falls below -10°C when compressor starts, the compressor frequency will be regulated up to 600 seconds.

16.3.5 Cold Draught Prevention Control

- When indoor pipe temperature is low, cold draught operation starts where indoor fan speed will be reduced.

16.3.6 Deice Operation

- When outdoor pipe temperature and outdoor air temperature is low, deice operation start where indoor fan motor and outdoor fan motor stop and operation LED blinks.

16.3.7 Low Pressure Protection Control


- During low ambient heating operation, if the pipe temperature drops below -24°C, the max frequency will be reduced and limited.
- If it does not rises after 3 minutes, the compressor will stop.
- The compressor will start again if the pipe temperature rises above -20°C.

17. Servicing Mode


17.1 TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)

- The Test Run operation will be activated by short-circuiting CN-S (Pin 1 & 2) at outdoor unit PCB after power supplied to outdoor unit terminal 1 and 2. The unit forced to run rated frequency cooling operation mode.

17.1.1 CU-Z25CBEA CU-Z35CBEA



17.1.2 CU-Z50CBEA CU-Z60CBEA



18. Troubleshooting Guide


18.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle. Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan. The normal outlet air temperature and pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

Normal Pressure and Outlet Air Temperature (Standard)

	Gas Pressure MPa (kg/cm ² G)	Outlet air Temperature (°C)
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)	13 ~ 17
Heating Mode	2.0 ~ 2.7 (20 ~ 27)	32 ~ 42

*Condition: • Indoor fan speed = High
• Outdoor temperature 35°C at the cooling mode and 7°C at the heating mode
• Compressor operates at rated frequency



18.1.1 Relationship Between the Condition of the Air Conditioner and Pressure and Electric Current

Condition of the air conditioner	Cooling Mode			Heating Mode		
	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Insufficient refrigerant (gas leakage)	↘	↘	↘	↘	↘	↘
Clogged capillary tube or Strainer	↘	↘	↘	↗	↗	↗
Short circuit in the indoor unit	↘	↘	↘	↗	↗	↗
Heat radiation deficiency of the outdoor unit	↗	↗	↗	↘	↘	↘
Inefficient compression	↗	↘	↘	↗	↘	↘

- Carry out the measurement of pressure, electric current, and temperature fifteen minutes after an operation is started.


18.2 Breakdown Self Diagnosis Function

18.2.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- Once abnormality has occurred during operation, the unit will stop its operation, and OFF/ON operation LED OFF.

18.2.2 To Make a Diagnosis

During stop operation, press  on remote controller, and select 'System check'. [H00] "No memory of failure" display will be shown, then ▲ or ▼ button is pressed, diagnostic display code will be shown one by one in sequence. When abnormality content is as same as diagnostic display code, receiving sound of 'pep pep pep pep' is occurred and OFF/ON operation LED is lighted.



18.3 Error Codes Table

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Protection Operation	Problem	Check location
H00	No memory of failure	—	Normal operation	—	—
H11	Indoor/outdoor abnormal communication	After operation for 1 minute	Indoor fan only operation can start by entering into force cooling operation	Indoor/outdoor communication not establish	- Indoor/outdoor wire terminal - Indoor/outdoor PCB - Indoor/outdoor connection wire
H12	Indoor unit capacity unmatched	90s after power supply	—	Total indoor capability more than maximum limit or less than minimum limit, or number of indoor unit less than two	- Indoor/outdoor connection wire - Indoor/outdoor PCB - Specification and combination table in catalogue
H14	Indoor intake air temperature sensor abnormality	Continuous for 5s	—	Indoor intake air temperature sensor open or short circuit	Indoor intake air temperature sensor lead wire and connector
H15	Compressor temperature sensor abnormality	Continuous for 5s	—	Compressor temperature sensor open or short circuit	Compressor temperature sensor lead wire and connector
H16	Outdoor current transformer (CT) abnormality	—	—	Current transformer faulty or compressor faulty	Outdoor PCB faulty or compressor faulty
H19	Indoor fan motor mechanism lock	Continuous happen for 7 times	—	Indoor fan motor lock or feedback abnormal	- Fan motor lead wire and connector - Fan motor lock or block
H21	Indoor float switch operation abnormal	—	—	—	—
H23	Indoor heat exchanger temperature sensor 1 abnormality	Continuous for 5s	—	Indoor heat exchanger temperature sensor open or short circuit	Indoor heat exchanger temperature sensor lead wire and connector
H24	Indoor heat exchanger temperature sensor 2 abnormality	Continuous for 5s	—	Indoor heat exchanger temperature sensor 2 open or short circuit	Indoor heat exchanger temperature sensor 2 lead wire and connector
H27	Outdoor air temperature sensor abnormality	Continuous for 5s	—	Outdoor air temperature sensor open or short circuit	Outdoor air temperature sensor lead wire and connector
H28	Outdoor heat exchanger temperature sensor 1 abnormality	Continuous for 5s	—	Outdoor heat exchanger temperature sensor 1 open or short circuit	Outdoor heat exchanger temperature sensor 1 lead wire and connector
H30	Outdoor discharge pipe temperature sensor abnormality	Continuous for 5s	—	Outdoor discharge pipe temperature sensor open or short circuit	Outdoor discharge pipe temperature sensor lead wire and connector
H32	Outdoor heat exchanger temperature sensor 2 abnormality	Continuous for 5s	—	Outdoor heat exchanger temperature sensor 2 open or short circuit	Outdoor heat exchanger temperature sensor 2 lead wire and connector
H34	Outdoor heat sink temp. sensor abnormality	Continuous for 2s	—	Outdoor heat sink temperature sensor open or short circuit	Outdoor heat sink sensor
H35	Indoor drain water adverse current abnormal	—	—	—	—
H36	Outdoor gas pipe temperature sensor abnormality	Continuous for 5s	Heating protection operation only	Outdoor gas pipe temperature sensor open or short circuit	Outdoor gas pipe temperature sensor lead wire and connector
H37	Outdoor liquid pipe temperature sensor abnormality	Continuous for 5s	Cooling protection operation only	Outdoor liquid pipe temperature sensor open or short circuit	Outdoor liquid pipe temperature sensor lead wire and connector
H39	Abnormal indoor operating unit or standby units	3 times happen within 40 minutes	—	Wrong wiring and connecting pipe, expansion valve abnormality, indoor heat exchanger sensor open circuit	- Check indoor/outdoor connection wire and connection pipe - Indoor heat exchanger sensor lead wire and connector - Expansion valve and lead wire and connector

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Protection Operation	Problem	Check location
H41	Abnormal wiring or piping connection	—	—	Wrong wiring and connecting pipe, expansion valve abnormality	• Check indoor/outdoor connection wire and connection pipe • Expansion valve and lead wire and connector
H64	Outdoor high pressure sensor abnormality	Continuous for 1 minutes	—	High pressure sensor open circuit during compressor stop	• High pressure sensor • Lead wire and connector
H97	Outdoor fan motor mechanism lock	2 times happen within 30 minutes	—	Outdoor fan motor lock or feedback abnormal	• Outdoor fan motor lead wire and connector • Fan motor lock or block
H98	Indoor high pressure protection	—	—	Indoor high pressure protection (Heating)	• Check indoor heat exchanger • Air filter dirty • Air circulation short circuit
H99	Indoor operating unit freeze protection	—	—	Indoor freeze protection (Cooling)	• Check indoor heat exchanger • Air filter dirty • Air circulation short circuit
F11	4-way valve switching abnormality	4 times happen within 30 minutes	—	4-way valve switching abnormal	• 4-way valve • Lead wire and connector
F17	Indoor standby units freezing abnormality	3 times happen within 40 minutes	—	Wrong wiring and connecting pipe, expansion valve leakage, indoor heat exchanger sensor open circuit	• Check indoor/outdoor connection wire and pipe • Indoor heat exchanger sensor lead wire and connector • Expansion valve lead wire and connector
F90	Power factor correction (PFC) circuit protection	4 times happen within 10 minutes	—	Power factor correction circuit abnormal	• Outdoor PCB faulty
F91	Refrigeration cycle abnormality	2 times happen within 20 minutes	—	Refrigeration cycle abnormal	• Insufficient refrigerant or valve close
F93	Compressor abnormal revolution	4 times happen within 20 minutes	—	Compressor abnormal revolution	• Power transistor module faulty or compressor lock
F94	Compressor discharge overshoot protection	4 times happen within 30 minutes	—	Compressor discharge pressure overshoot	• Check refrigeration system
F95	Outdoor cooling high pressure protection	4 times happen within 20 minutes	—	Cooling high pressure protection	• Check refrigeration system • Outdoor air circuit
F96	Power transistor module overheating protection	4 times happen within 30 minutes	—	Power transistor module overheat	• PCB faulty • Outdoor air circuit (fan motor)
F97	Compressor overheating protection	3 times happen within 30 minutes	—	Compressor overheat	• Insufficient refrigerant
F98	Total running current protection	3 times happen within 20 minutes	—	Total current protection	• Check refrigeration system • Power source or compressor lock
F99	Outdoor direct current (DC) peak detection	Continuous happen for 7 times	—	Power transistor module current protection	• Power transistor module faulty or compressor lock

18.4 Troubleshooting Flowchart

18.4.1 H11 (Indoor/Outdoor Abnormal Communication)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused

- Faulty indoor unit PCB.
- Faulty outdoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wrong wiring.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- Indoor unit-outdoor unit signal transmission error due to disturbed waveform.

Troubleshooting



During diagnosis indoor/outdoor PCB always remove panels & check external DC components conditions and the DC component connector for burn marks on the PCB

- The defective DC component is most likely the cause of the main PCB failure.
 - Temperature Sensor
 - V-Coil
 - DC Fan Motor
 - Air Swing Motor
 - Nanoe Generator
 - Compressor
- Check all the DC components wire for any sign of damage which might caused short circuit.
- Replace any damaged external DC components connected to indoor/outdoor PCB.
- Refer to respective model service manual wiring & electronic circuit diagrams for test results of DC components.

18.4.2 H12 (Indoor/Outdoor Capacity Rank Mismatched)


Malfunction Decision Conditions

- During startup, error code appears when different types of indoor and outdoor units are interconnected.

Malfunction Caused

- Wrong models interconnected.
- Wrong indoor unit or outdoor unit PCBs mounted.
- Indoor unit or outdoor unit PCBs defective.
- Indoor-outdoor unit signal transmission error due to wrong wiring.
- Indoor-outdoor unit signal transmission error due to breaking of wire 3 in the connection wires between the indoor and outdoor units.

Troubleshooting



18.4.3 H14 (Indoor Intake Air Temperature Sensor Abnormality)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the indoor intake air temperature sensor are used to determine sensor errors.

Malfunction Caused


- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.4.4 H15 (Compressor Temperature Sensor Abnormality)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor compressor temperature sensor are used to determine sensor errors.

Malfunction Caused


- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.4.5 H16 (Outdoor Current Transformer)


Malfunction Decision Conditions

- An input current, detected by Current Transformer (CT) / Current Sensor (SEN1), is below threshold value when the compressor is operating at certain frequency value for 3 minutes.

Malfunction Caused


- Lack of gas.
- Broken current transformer / Current sensor.
- Broken Outdoor PCB.
- Compressor low compression.

Troubleshooting



Quick confirmation - Current Transformer condition

Confirm CT conditions



Use multi meter to check if Current Transformer condition has shorted during power supply off

Condition	Judgment
SHORT	OK
OPEN	OUT (Replace PCB)

18.4.6 H19 (Indoor Fan Motor – DC Motor Mechanism Locked)



Malfunction Decision Conditions

- The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 50 rpm).

Malfunction Caused

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation stops due to Hall IC malfunction.
- Operation error due to faulty indoor unit PCB.

Troubleshooting



Pin	Function
1	Main Supply to fan motor (Vm)
4	Ground (GND)
5	Supply to Fan motor PCB (Vcc)
6	Feedback Signal (FG) (Revolution Pulse Output)
7	Speed Control Voltage Input (Vsp)

18.4.7 H23 (Indoor Pipe Temperature Sensor Abnormality)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the indoor heat exchanger temperature sensor are used to determine sensor errors.

Malfunction Caused


- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.4.8 H24 (Indoor Pipe Temperature Sensor 2 Abnormality) (Only for Model Come with 2 Pipe Sensor)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the indoor heat exchanger temperature sensor 2 are used to determine sensor errors.

Malfunction Caused


- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.4.9 H27 (Outdoor Air Temperature Sensor Abnormality)



Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.10 H28 (Outdoor Pipe Temperature Sensor Abnormality)



Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.11 H30 (Compressor Discharge Temperature Sensor Abnormality)



Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.12 H32 (Outdoor Heat Exchanger Temperature Sensor 2 Abnormality)



Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor heat exchanger temperature sensor 2 are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.13 H34 (Outdoor Heat Sink Temperature Sensor Abnormality)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor heat sink temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.14 H36 (Outdoor Gas Pipe Sensor Abnormality)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor gas pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.15 H37 (Outdoor Liquid Pipe Temperature Sensor Abnormality)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor liquid pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

Troubleshooting



18.4.16 H97 (Outdoor Fan Motor – DC Motor Mechanism Locked)


Malfunction Decision Conditions

- The running current detected by the current sensing feedback circuit during fan motor operation is used to determine abnormal fan motor.

Malfunction Caused

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation error due to faulty outdoor unit PCB.

Troubleshooting



Model		CU-Z25/35CBEA	CU-Z50/60CBEA
Fan Motor		L6CAYYYL0064	L6CAYYYL0076
Winding Resistance (Ω)	1(W) - 2(V)	40.3 (1 Phase) / 80.5±8.1 (2 Phase) at 20°C	20.8 (1 Phase) / 41.6±4.2 (2 Phase) at 20°C
	2(V) - 3(U)		
	1(W) - 3(U)		

CN-MTR2 Fan Motor U, V & W Voltage = 30~125VAC depends on speed & model.
CN-MTR2 Fan Motor Supply Voltage = 280 - 340VDC.



Measure the winding resistance from fan motor connector

18.4.17 H97 (Outdoor Fan Motor – DC Motor Mechanism Locked *with inverter checker)


Malfunction Decision Conditions

- The running current detected by the current sensing feedback circuit during fan motor operation is used to determine abnormal fan motor.

Malfunction Caused

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation error due to faulty outdoor unit PCB.

Troubleshooting



Model		CU-Z25/35CBEA	CU-Z50/60CBEA
Fan Motor		L6CAYYYL0064	L6CAYYYL0076
Winding Resistance (Ω)	1(W) - 2(V)	40.3 (1 Phase) / 80.5±8.1 (2 Phase) at 20°C	20.8 (1 Phase) / 41.6±4.2 (2 Phase) at 20°C
	2(V) - 3(U)		
	1(W) - 3(U)		

CN-MTR2 Fan Motor U, V & W Voltage = 30~125VAC depends on speed & model.
CN-MTR2 Fan Motor Supply Voltage = 280 - 340VDC.



Measure the winding resistance from fan motor connector

18.4.18 H98 (Indoor High Pressure Protection)



Malfunction Decision Conditions

- Indoor high pressure is detected when indoor heat exchanger is detecting very high temperature when the unit is operating in heating operation.
- Phenomena: unit is stopping and re-starting very often in heating mode.
- The temperature detected by the indoor pipe temperature sensor is abnormal.

Malfunction Caused

- Indoor heat exchanger thermistor.
- Clogged air filter or heat exchanger.
- Over-bent pipe (liquid side).
- Dust accumulation on the indoor unit heat exchanger
- Air short circuit
- Detection error due to faulty indoor unit PCB

Troubleshooting



18.4.19 H99 (Indoor Freeze Prevention Protection: Cooling or Soft Dry)

Error Code will not display (no Timer LED blinking) but store in EEPROM



Malfunction Decision Conditions

- Freeze prevention control takes place (when indoor pipe temperature is lower than 2°C).

Malfunction Caused

- Air short circuit at indoor unit.
- Clogged indoor unit air filter.
- Dust accumulation on the indoor unit heat exchanger.
- 2/3 way valve closed.
- Faulty indoor unit fan motor.
- Refrigerant shortage (refrigerant leakage).
- Clogged expansion valve or strainer.
- Faulty indoor pipe temperature sensor.
- Faulty indoor unit PCB.

Troubleshooting



18.4.20 F11 (4-way Valve Switching Failure)


Malfunction Decision Conditions

- When indoor heat exchanger is cold during heating (except deice) or when indoor heat exchanger is hot during cooling and compressor operating, the 4-way valve is detected as malfunction.

Malfunction Caused

- Indoor heat exchanger (pipe) thermistor
- 4-way valve or v-coil malfunction
- Outdoor unit PCB malfunction

Troubleshooting



* Check gas side pipe – for hot gas flow in cooling mode

18.4.21 F17 (Indoor Standby Units Freezing Abnormality)

Malfunction Decision Conditions

- When the different between indoor intake air temperature and indoor pipe temperature is above 10°C or indoor pipe temperature is below -1.0°C.


Remark:

When the indoor standby unit is freezing, the outdoor unit transfers F17 error code to the corresponding indoor unit and H39 to other indoor unit(s).

Malfunction Caused

- Wrong wiring connection
- Faulty sensor
- Faulty expansion valve

Troubleshooting



18.4.22 F90 (Power Factor Correction Protection)


Malfunction Decision Conditions

- To maintain DC voltage level supply to power transistor.
- To detect high DC voltage level after rectification.

Malfunction Caused

- During startup and operation of cooling and heating, when Power Factor Correction (PFC) protection circuitry at the outdoor unit main PCB senses abnormal DC voltage level for power transistors.
- DC voltage peak due to compressor windings not uniform.
- Outdoor unit PCB malfunction.

Troubleshooting




Model	CU-Z25/35CBEA	CU-Z50/60CBEA
Reactor	G0C392J00028	G0C392J00027
Inductance (mH)	3.9 ± 5%	3.9 ± 5%

Resistance of Compressor Windings

MODEL	CU-Z25/35CBEA	CU-Z50/60CBEA
CONNECTION	9RS102XFA21	9RD132XAA21
U-V	1.211 Ω	1.897 Ω
U-W	1.211 Ω	1.907 Ω
V-W	1.211 Ω	1.882 Ω

Note: Resistance at 20°C of ambient temperature.



18.4.23 F91 (Refrigeration Cycle Abnormality)



Malfunction Decision Conditions

- The input current is low while the compressor is running at higher than the setting frequency.

Malfunction Caused

- Refrigerant shortage (refrigerant leakage).
- Poor compression performance of compressor.
- 2/3 way valve closed.
- Detection error due to faulty indoor intake air or indoor pipe temperature sensors.

Troubleshooting



18.4.24 F93 (Compressor Rotation Failure)


Malfunction Decision Conditions

- A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused

- Compressor terminal (U, V & W) reversed or disconnect.
- Faulty Outdoor PCB.
- Faulty compressor.

Troubleshooting




Resistance of Compressor Windings

MODEL	CU-Z25/35CBEA	CU-Z50/60CBEA
CONNECTION	9RS102XFA21	9RD132XAA21
U-V	1.211 Ω	1.897 Ω
U-W	1.211 Ω	1.907 Ω
V-W	1.211 Ω	1.882 Ω

Note: Resistance at 20°C of ambient temperature.

Checking the outdoor PCB (Inverter Power Transistor - IPM)
 Check IPM input Voltage P-N = (280~340 VDC)



- Check U-V, V-W, W-U having same AC Voltage (200~240 VAC or 150~180 VAC depends on speed & model) -
 - Check N-V, N-U, N-W having same DC Voltage (130~170 VDC depends on speed & model)
- If not obtained during compressor operating high frequency max
 = Replace outdoor PCB

18.4.25 F93 (Compressor Rotation Failure *with inverter checker)


Malfunction Decision Conditions

- A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused

- Compressor terminal (U, V & W) reversed/disconnect.
- Faulty Outdoor PCB.
- Faulty compressor.

Troubleshooting



Resistance of Compressor Windings

MODEL	CU-Z25/35CBEA	CU-Z50/60CBEA
CONNECTION	9RS102XFA21	9RD132XAA21
U-V	1.211 Ω	1.897 Ω
U-W	1.211 Ω	1.907 Ω
V-W	1.211 Ω	1.882 Ω

Note: Resistance at 20°C of ambient temperature.



18.4.26 F95 (Outdoor High Pressure Protection: Cooling or Soft Dry)


Malfunction Decision Conditions

- During operation of cooling or soft dry, when outdoor unit heat exchanger high temperature data is detected by the outdoor unit heat exchanger thermistor.

Malfunction Caused


- Outdoor heat exchanger temperature rise due to short-circuit of hot discharge air flow.
- Outdoor heat exchanger temperature rise due to defective of outdoor fan motor.
- Outdoor heat exchanger temperature rise due to defective outdoor heat exchanger thermistor.
- Outdoor heat exchanger temperature rise due to defective of outdoor unit PCB.

Troubleshooting



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.4.27 F96 (IPM Overheating)

Malfunction Decision Conditions

- During operating of cooling and heating, when IPM temperature data (120°C) is detected by the IPM temperature sensor.

Multi Models only

- Compressor Overheating: During operation of cooling and heating, when the compressor OL is activated.
- Heat Sink Overheating: During operation of cooling and heating, when heat sink temperature data (90°C) is detected by the heat sink temperature sensor.


Malfunction Caused

- IPM overheats due to short circuit of hot discharge air flow.
- IPM overheats due to defective of outdoor fan motor.
- IPM overheats due to defective of internal circuitry of IPM.
- IPM overheats due to defective IPM temperature sensor.

Multi Models Only

- Compressor OL connector poor contact.
- Compressor OL faulty.

Troubleshooting



18.4.28 F97 (Compressor Overheating)




Malfunction Decision Conditions

- During operation of cooling and heating, when compressor tank temperature data (107°C) is detected by the compressor tank temperature sensor.

Malfunction Caused

- Faulty compressor tank temperature sensor
- 2/3 way valve closed
- Refrigerant shortage (refrigerant leakage)
- Faulty outdoor unit PCB
- Faulty compressor

Troubleshooting



CN-STM1 (White)	
Blue	Com
Black	Coil 1
Yellow	Coil 2
Red	Coil 3
Orange	Coil 4
ACXA43C07230	
Com vs Coil 1, 2, 3 & 4 = 46 ± 3.0Ω	

18.4.29 F98 (Input Over Current Detection)


Malfunction Decision Conditions

- During cooling and heating operation, when an input over-current is detected by checking the input current value being detected by current transformer (CT) or current sensor (SEN1) with the compressor running.

Malfunction Caused

- Excessive refrigerant.
- Faulty outdoor unit PCB.
- Faulty Compressor.
- Faulty inverter main circuit electrolytic capacitor.

Troubleshooting



Model	Z25/35/50/60*
Over-current value (A)	14.66

18.4.30 F99 (DC Peak Detection)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, when inverter DC peak data is received by the outdoor internal DC peak sensing circuitry.

Malfunction Caused

- DC current peak due to compressor failure.
- DC current peak due to defective power transistor(s).
- DC current peak due to defective outdoor unit PCB.
- DC current peak due to short circuit of DC components.

Troubleshooting




Resistance of Compressor Windings

MODEL	CU-Z25/35CBEA	CU-Z50/60CBEA
CONNECTION	9RS102XFA21	9RD132XAA21
U-V	1.211 Ω	1.897 Ω
U-W	1.211 Ω	1.907 Ω
V-W	1.211 Ω	1.882 Ω

Note: Resistance at 20°C of ambient temperature.

Checking the outdoor PCB (Inverter Power Transistor - IPM)
Check IPM input Voltage P-N = (280~340 VDC)



- Check U-V, V-W, W-U having same AC Voltage (200~240 VAC or 150~180 VAC depends on speed & model)
 - Check N-V, N-U, N-W having same DC Voltage (130~170 VDC depends on speed & model)
- If not obtained during compressor operating high frequency max
= Replace outdoor PCB

18.4.31 F99 (DC Peak Detection *with inverter checker)


Malfunction Decision Conditions

- During startup and operation of cooling and heating, when inverter DC peak data is received by the outdoor internal DC peak sensing circuitry.

Malfunction Caused

- DC current peak due to compressor failure.
- DC current peak due to defective power transistor(s).
- DC current peak due to defective outdoor unit PCB.
- DC current peak due to short circuit of DC components.

Troubleshooting



Resistance of Compressor Windings

MODEL	CU-Z25/35CBEA	CU-Z50/60CBEA
CONNECTION	9RS102XFA21	9RD132XAA21
U-V	1.211 Ω	1.897 Ω
U-W	1.211 Ω	1.907 Ω
V-W	1.211 Ω	1.882 Ω

Note: Resistance at 20°C of ambient temperature.



19. Disassembly and Assembly Instructions

WARNING

High Voltage is generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.
Working at a height involves a risk of a person falling. Practice safety standards according to each country requirement.

CAUTION


To maintain the indoor unit's appearance, some precaution needs to be taken during installation or servicing activities.

- 1) Avoid direct contact between the indoor unit with rough or sharp surfaces that could cause scratches on the matte surface. (e.g. floor, installation tools, fingernails)
- 2) When placing the unit on the ground, ensure there is lining such as soft cloth between the unit and the ground surface / floor to prevent any scratching.
- 3) When handling the unit, it is encourage to wear gloves to avoid scratches by sharp or rough items (e.g. fingernails, screwdriver/powertool, rings, etc)
- 4) When cleaning the unit, use soft damp cloth. For tougher stains, you can use a bleach-free wet wipe. Test on a small area first. Do not use harsh chemicals such as thinner to clean the grilles which could corrode or leave marks on the paint coating.
- 5) When servicing the unit, gloves should be worn to prevent injuries from sharp edges on certain components.

19.1 Indoor Electronic Controller, Blower Fan, Fan Motor & Drain Motor Removal Procedure


19.1.1 To Remove Cabinet Bottom Plate

- 1 Unscrew 14 screws on the cabinet bottom plate, 10 screws on the cabinet top plate and detach cabinet bottom plate and cabinet top plate from unit.




19.1.2 To Remove Electronic Controller

- 1 Unscrew the 2 screws on the Control Board and open the Control Board Cover.





2 Detach all connectors as labeled from the electronic controller. Then pull out main controller gently.




19.1.3 To Remove Fan Motor and Blower Fan

- 1 Detach the Upper and Inner Casing
- 2 Disengage the 4 catches (2 each on the left and right) on the Air Guide.




- 3 Unscrew the 2 screws on the Fan Motor Bracket and detach Fan Motor Bracket.
- 4 Remove the Fan Motor and Blower Fan from the unit.
- 5 Use a 3.0 mm hexagonal wrench to loosen the bolts connecting the Fan Motor and Fan. Detach the shaft connecting the Fan Motor and Blower Fan. (Reminder: Beware of fall down when removing the blower fan.)




19.1.4 To Remove the Drain Motor


- 1 Unscrew the 1 screw on the Side Plate and remove Drain Pan from the unit.




- 2 Unscrew 5 screws on the Evaporator and remove 2 sensor from holder and remove Evaporator from the unit.



- 3 Unscrew 4 screws, 1 nut and 1 Spring Clip on the Drain Motor Bracket and remove Drain Motor from unit.



- 4 Unscrew 3 screws on the Drain Motor and detach the Drain Motor from Drain Motor Bracket.



19.2 Outdoor Electronic Controller Removal Procedure

19.2.1 CU-Z25CBEA

⚠ Caution! When handling electronic controller, be careful of electrostatic discharge.

- 1 Remove the 5 screws of the Top Panel.




Fig. 1

- 2 Remove the 6 screws of the Front Panel.




Fig. 2

- 3 Remove the screw of the Terminal Board Cover.
4 Remove the Top Cover of the Control Board by 4 hooks.




Fig. 3

- 5 Remove the Control Board as follows:




Fig. 4




Fig. 5




Fig. 6

19.2.2 CU-Z35CBEA

⚠ Caution! When handling electronic controller, be careful of electrostatic discharge.

- 1 Remove the 5 screws of the Top Panel.




Fig. 1

- 2 Remove the 8 screws of the Front Panel.




Fig. 2

- 3 Remove the screw of the Terminal Board Cover.

- 4 Remove the Top Cover of the Control Board by 4 hooks.




Fig. 3

- 5 Remove the Control Board as follows:




Fig. 4




Fig. 5




Fig. 6

19.2.3 CU-Z50CBEA CU-Z60CBEA

⚠ Caution! When handling electronic controller, be careful of electrostatic discharge.

- 1 Remove the 5 screws of the Top Panel.




Fig. 1

- 2 Remove the 8 screws of the Front Panel.




Fig. 2

- 3 Remove the screw of the Terminal Board Cover.
- 4 Remove the Top Cover of the Electronic Controller by 4 hooks.




Fig. 3

- 5 Remove 2 screws for the plate of Terminal Board Cover.




Fig. 4

- 6 Remove the Control Board.




Fig. 5

7. Remove the 4 screws of the Electronic Controller.




Fig. 6

20. Technical Data

Technical data provided are based on the air conditioner running under free frequency.

20.1 Cool Mode Performance Data

Unit setting: Standard piping length, Hi Fan, Cool mode at 16°C Voltage: 230V

20.1.1 CS-Z25CD3EAW CU-Z25CBEA

Indoor (°C)		Outdoor DB (°C)																				
DB	WB	-10			-7			0			5			16			25			35		
		TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	2451	2402	514	2770	2659	529	3058	2817	510	3155	2837	451	3268	2702	345	2635	2403	527	2500	2280	580
	22.0	2861	2133	594	2903	1850	481	2730	1686	566	2741	1735	588	2861	2009	548	2996	1922	648	3001	1925	583
23	15.7	2822	2440	597	2517	2374	581	2307	2261	611	2147	2104	297	2246	2201	548	2240	2228	637	2361	2348	586
	18.4	3061	1928	601	2584	1861	587	2505	1793	586	2476	1824	272	2604	1943	579	2798	1968	634	2602	1830	586
20	13.3	2245	1569	336	2040	1999	409	1828	1792	373	1987	1948	629	1019	998	193	1693	1659	251	2141	2099	589
	15.8	2767	2504	636	2311	1803	627	2302	1783	599	2216	1751	691	1641	1518	304	2169	1631	387	2414	1816	589

(Dry bulb value based on 46% humidity)

20.1.2 CS-Z35CD3EAW CU-Z35CBEA

Indoor (°C)		Outdoor DB (°C)																				
DB	WB	-10			-7			0			5			16			25			35		
		TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	3288	3107	801	3716	3215	825	4102	3407	795	4233	3431	702	4384	3267	538	3535	2906	821	3500	2877	910
	22.0	3838	2579	926	3894	2236	749	3662	2039	883	3678	2098	916	3838	2430	854	4020	2324	1009	4026	2328	908
23	15.7	3786	2950	931	3377	2870	905	3095	2818	952	2880	2686	464	3013	2843	854	3005	2695	992	3167	2840	913
	18.4	4106	2332	936	3466	2250	915	3361	2168	913	3321	2206	423	3494	2349	902	3754	2379	989	3491	2213	913
20	13.3	3011	1897	523	2736	2602	638	2452	2526	581	2666	2612	979	1367	1553	301	2271	2175	392	2873	2751	917
	15.8	3713	3028	992	3100	2180	977	3088	2156	934	2972	2117	1078	2202	1835	474	2909	1972	603	3239	2196	918

(Dry bulb value based on 46% humidity)

20.1.3 CS-Z50CD3EAW CU-Z50CBEA

Indoor (°C)		Outdoor DB (°C)																				
DB	WB	-10			-7			0			5			16			25			35		
		TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	6266	4038	1209	6319	4046	1122	6208	4018	1197	6282	4044	1125	6162	3932	1125	2961	2594	413	5100	3578	1560
	22.0	6794	3202	1220	7021	3245	1033	7003	3238	971	6926	3196	1120	6823	3169	1115	5150	2636	878	5326	2687	1679
23	15.7	5084	3865	1077	5268	3745	913	5135	3682	834	5794	3960	1102	5461	3801	991	2960	2513	484	4300	3333	1551
	18.4	6328	3194	1029	6137	3158	1202	6081	3138	1251	6040	3118	1219	7117	3556	1388	4616	2109	838	4870	2780	1562
20	13.3	3927	3176	718	3968	3194	722	4151	3281	635	3863	3107	732	4263	3316	747	2958	2565	554	3600	3009	1559
	15.8	5293	2952	1028	5716	3122	907	5911	3204	1063	4407	2535	808	4969	2829	818	4082	2455	799	4433	2696	1557

(Dry bulb value based on 46% humidity)

20.1.4 CS-Z60CD3EAW CU-Z60CBEA

Indoor (°C)		Outdoor DB (°C)																				
DB	WB	-10			-7			0			5			16			25			35		
		TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	7335	4728	1573	7398	4737	1461	7268	4704	1558	7354	4735	1465	7214	4604	1465	3467	3037	538	6000	4210	2040
	22.0	7954	3748	1589	8220	3799	1345	8199	3791	1264	8108	3741	1459	7988	3710	1451	6029	3086	1142	6235	3146	2185
23	15.7	5952	4524	1403	6167	4385	1188	6012	4311	1086	6784	4636	1434	6394	4450	1290	3465	2942	630	5035	3902	2020
	18.4	7408	3739	1340	7185	3697	1564	7119	3674	1628	7072	3650	1587	8332	4163	1807	5404	2469	1091	5702	3255	2033
20	13.3	4598	3718	935	4646	3739	940	4860	3841	826	4522	3637	952	4991	3882	973	3463	3003	722	4214	3523	2030
	15.8	6196	3456	1339	6692	3654	1181	6920	3752	1383	5159	2968	1052	5817	3313	1065	4779	2874	1040	5190	3156	2026

(Dry bulb value based on 46% humidity)

TC - Total Cooling Capacity (W)

SHC - Sensible Heat Capacity (W)

IP - Input Power (W)

20.2 Heat Mode Performance Data

Unit setting: Standard piping length, Hi Fan, Heat mode at 30°C Voltage: 230V

20.2.1 CS-Z25CD3EAW CU-Z25CBEA

Indoor (°C)	Outdoor WB (°C)									
DB	-15		-7		2		7		12	
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
24	2379	1181	2155	1081	2846	1048	3028	801	3714	802
20	2380	1040	2600	1140	3343	1110	3204	800	4151	859
16	2246	1019	2412	923	3391	995	3477	802	4417	857

20.2.2 CS-Z35CD3EAW CU-Z35CBEA

Indoor (°C)	Outdoor WB (°C)									
DB	-15		-7		2		7		12	
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
24	2479	1340	2486	1166	3150	1190	3969	1102	4868	1103
20	2480	1180	3000	1230	3700	1260	4200	1100	5442	1181
16	2341	1156	2783	996	3754	1129	4558	1103	5789	1178

20.2.3 CS-Z50CD3EAW CU-Z50CBEA

Indoor (°C)	Outdoor WB (°C)									
DB	-15		-7		2		7		12	
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
24	3571	1827	4450	1971	4995	1980	5805	1814	6285	1812
20	3806	1815	4500	1950	5220	1950	6100	1820	6849	1823
16	4060	1797	4049	1724	5249	1907	6695	1824	7314	1819

20.2.4 CS-Z60CD3EAW CU-Z60CBEA

Indoor (°C)	Outdoor WB (°C)									
DB	-15		-7		2		7		12	
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP
24	3789	1996	5043	2345	5550	2335	6531	2153	7071	2151
20	4038	1983	5100	2320	5800	2300	7000	2160	7705	2163
16	4307	1964	4589	2051	5832	2250	7532	2164	8228	2159

TC - Total Heating Capacity (W)

IP - Input Power (W)

20.3 Fan Performance


20.3.1 CS-Z25CD3EAW

Test Report

Tap	Static Pressure (Pa)	Airflow (m ³ /min)
Lo	-0.1	10.37
	2.4	10.09
	15.7	8.45
	25.6	6.89
	33.2	5.54
	40.6	4.35
Me	-0.1	11.73
	10.5	10.82
	27.9	9.40
	40.3	8.00
	50.2	6.75
	58.1	5.73
	62.7	4.66

Tap	Static Pressure (Pa)	Airflow (m ³ /min)
Hi	0.1	13.10
	24.4	11.66
	44.6	10.37
	60.4	9.12
	74.5	7.98
	84.1	6.97
	90.3	6.13
	93.4	5.22
Hi Fan (Hi Static P selected)	-0.1	15.04
	70.3	10.78
	86.1	9.59
	97.9	8.48
	107.5	7.49
	114.2	6.73
	121.3	5.99

Fan Performance Curve



Static Pressure Upper Limit

Static Pressure (Pa)	Airflow (m ³ /min)
63	7.5
50	6.7
39	6.0
32	5.4

	RPM	Static Pressure (Pa)	Airflow (m ³ /min)
Hi Fan (Hi Static P selected)	1260	43	10.5
Hi Fan (Rated)	1100	25	10.5
Me Fan (Rated)	990	20	9.3
Lo Fan (Rated)	880	15	8.2

Static Pressure Lower Limit

Static Pressure (Pa)	Airflow (m ³ /min)
10	14.2
5	12.6
2	11.5
0	10.4


20.3.2 CS-Z35CD3EAW

Test Report

Tap	Static Pressure (Pa)	Airflow (m³/min)
Lo	-0.1	10.37
	2.4	10.09
	15.7	8.45
	25.6	6.89
	33.2	5.54
	40.6	4.35
Me	-0.1	11.97
	10.5	11.04
	27.9	9.59
	40.3	8.16
	50.2	6.88
	58.1	5.85
	62.7	4.75

Tap	Static Pressure (Pa)	Airflow (m³/min)
Hi	0.1	13.58
	24.4	12.09
	44.6	10.74
	60.4	9.45
	74.5	8.27
	84.1	7.23
	90.3	6.35
	93.4	5.41
Hi Fan (Hi Static P selected)	-0.1	15.51
	70.3	11.13
	86.1	9.89
	97.9	8.75
	107.5	7.73
	114.2	6.94
	121.3	6.18

Fan Performance Curve



Static Pressure Upper Limit	
Static Pressure (Pa)	Airflow (m³/min)
65	8.2
50	7.6
39	6.6
32	5.4

	RPM	Static Pressure (Pa)	Airflow (m³/min)
Hi Fan (Hi Static P selected)	1300	44	11.2
Hi Fan (Standard)	1140	25	11.2
Me Fan (Standard)	1010	20	9.5
Lo Fan (Standard)	880	15	8.2

Static Pressure Lower Limit	
Static Pressure (Pa)	Airflow (m³/min)
10	14.6
5	13.1
2	11.7
0	10.4


20.3.3 CS-Z50CD3EAW

Test Report

Tap	Static Pressure (Pa)	Airflow (m ³ /min)
Lo	-0.1	11.08
	2.5	10.78
	16.4	9.02
	26.7	7.36
	34.7	5.92
	42.4	4.65
Me	-0.1	14.10
	10.7	13.01
	28.4	11.29
	41.0	9.61
	51.1	8.11
	59.1	6.89
	63.8	5.60

Tap	Static Pressure (Pa)	Airflow (m ³ /min)
Hi	0.1	17.15
	24.4	15.27
	44.6	13.57
	60.4	11.94
	74.5	10.45
	84.1	9.13
	90.3	8.02
	93.4	6.83
Hi Fan (Hi Static P selected)	-0.1	19.06
	58.2	13.56
	72.9	12.02
	86.4	10.59
	97.9	9.42
	103.7	8.42
	112.8	7.55

Fan Performance Curve



Static Pressure Upper Limit

Static Pressure (Pa)	Airflow (m ³ /min)
75	12.7
65	11.5
50	8.4
35	6.0

	RPM	Static Pressure (Pa)	Airflow (m ³ /min)
Hi Fan (Hi Static P selected)	1600	49	15.3
Hi Fan (Standard)	1440	25	15.3
Me Fan (Standard)	1190	20	12.1
Lo Fan (Standard)	940	15	9.2

Static Pressure Lower Limit

Static Pressure (Pa)	Airflow (m ³ /min)
10	18.4
5	16.7
2	13.8
0	12.0


20.3.4 CS-Z60CD3EAW

Test Report

Tap	Static Pressure (Pa)	Airflow (m³/min)
Lo	-0.1	11.55
	2.4	11.24
	15.7	9.41
	25.6	7.67
	33.2	6.17
	40.6	4.85
Me	-0.1	14.57
	10.5	13.45
	27.9	11.67
	40.3	9.93
	50.2	8.38
	58.1	7.12
	62.7	5.79

Tap	Static Pressure (Pa)	Airflow (m³/min)
Hi	0.1	17.63
	24.4	15.69
	44.6	13.95
	60.4	12.27
	74.5	10.74
	84.1	9.38
	90.3	8.24
	93.4	7.02
Hi Fan (Hi Static P selected)	-0.1	19.57
	70.3	14.04
	86.1	12.48
	97.9	11.04
	107.5	9.75
	114.2	8.75
	121.3	7.80

Fan Performance Curve



Static Pressure Upper Limit	
Static Pressure (Pa)	Airflow (m³/min)
75	13.5
65	12.2
50	9.1
35	6.7

	RPM	Static Pressure (Pa)	Airflow (m³/min)
Hi Fan (Hi Static P selected)	1640	51	15.7
Hi Fan (Standard)	1480	25	15.7
Me Fan (Standard)	1230	21	12.6
Lo Fan (Standard)	980	17	9.4

Static Pressure Lower Limit	
Static Pressure (Pa)	Airflow (m³/min)
10	18.8
5	17.2
2	14.4
0	13.0

21. Service Data




Service data provided are based on the air conditioner running under rated frequency during forced cooling / forced heating mode.

21.1 Cool Mode Outdoor Air Temperature Characteristic




Condition

- Indoor room temperature: 27°C Dry Bulb/19°C Wet Bulb
- Unit setting: Standard piping length, forced cooling at 16°C, Hi fan
- Compressor frequency: Rated for cooling operation
- Piping length: 5m
- Voltage: 230V




21.1.1 CS-Z25CD3EAW CU-Z25CBEA






21.1.2 CS-Z35CD3EAW CU-Z35CBEA



21.1.3 CS-Z50CD3EAW CU-Z50CBEA



21.1.4 CS-Z60CD3EAW CU-Z60CBEA






21.2 Heat Mode Outdoor Air Temperature Characteristic




Condition

- Indoor room temperature: 20°C Dry Bulb/ -°C Wet Bulb
- Unit setting: Standard piping length, forced heating at 30°C, Hi fan
- Compressor frequency: Rated for Heating operation
- Piping length: 5m
- Voltage: 230V




21.2.1 CS-Z25CD3EAW CU-Z25CBEA






21.2.2 CS-Z35CD3EAW CU-Z35CBEA



21.2.3 CS-Z50CD3EAW CU-Z50CBEA




21.2.4 CS-Z60CD3EAW CU-Z60CBEA




21.3 Piping Length Correction Factor

The characteristic of the unit has to be corrected in accordance with the piping length.

21.3.1 CS-Z25CD3EAW CU-Z25CBEA




Cooling Capacity	
3	1.0096
5	1.0000
10	0.9781
20	0.9628



Heating Capacity	
3	1.0042
5	1.0000
10	0.9896
20	0.9688


Note: The graphs show the factor after added right amount of additional refrigerant.

21.3.2 CS-Z35CD3EAW CU-Z35CBEA



Cooling Capacity

3	1.0080
5	1.0000
10	0.9850
20	0.9656




Heating Capacity

3	1.0118
5	1.0000
10	0.9800
20	0.9392


Note: The graphs show the factor after added right amount of additional refrigerant.

21.3.3 CS-Z50CD3EAW CU-Z50CBEA CS-Z60CD3EAW CU-Z60CBEA



Cooling Capacity

3	1.0080
5	1.0000
10	0.9895
20	0.9656
30	0.9418



Heating Capacity

3	1.0118
5	1.0000
10	0.9800
20	0.9392
30	0.8966

Note: The graphs show the factor after added right amount of additional refrigerant.

SAFETY	REF NO.	PART NAME & DESCRIPTION	QTY.	CS-Z25CD3EAW	CS-Z35CD3EAW	REMARK
	1	CABINET TOP PLATE - COMPLETE	1	CWE03C1169	←	
	2	FOAMED STYRENE COMPLETE	1	CWG07C1094	←	
	3	FOAMED STYRENE COMPLETE	1	CWG07C1089	←	
	4	FOAMED STYRENE COMPLETE	1	CWG07C1090	←	
	5	BULKHEAD	1	CWD531059	←	
	6	CABINET SIDE PLATE - COMPLETE	1	CWE04C1565	←	
	7	CABINET SIDE PLATE - COMPLETE	1	ACXE04C07290	←	
	8	PARTICULAR PLATE	4	CWD912571	←	
	9	FAN MOTOR BRACKET	1	CWD541246	←	
	10	SCREW - FAN MOTOR BRACKET	6	CWH55406J	←	
⚠	11	PUMP - COMPLETE	1	ACXB53C00550	←	O
	12	ANTI - VIBRATION BUSHING	3	CWH501131	←	
⚠	13	FLOAT SWITCH COMPLETE	1	CWA12C1034	←	O
	14	DRAIN NOZZLE	1	CWH411027	←	
	15	FLEXIBLE PIPE - COMPLETE	1	CWH85C1120	←	
	16	PLATE SPRING	1	CWH711022	←	
	17	WIRE SPRING	1	CWH722018	←	
	18	PARTICULAR PIECE - COMPLETE	1	CWD93C1191	←	
	19	EVAPORATER - COMPLETE	1	ACXB30C16720	←	O
	20	FLARE NUT (1/4")	1	CWT251030	←	
	21	FLARE NUT (3/8")	1	CWT251031	←	
	22	HOLDER - SENSOR	2	CWH32143	←	
⚠	23	SENSOR COMPLETE	1	ACXA50C00030	←	O
	24	BLOWER WHEEL ASS'Y	2	ACXH01K00510	←	
⚠	25	FAN MOTOR	1	L6CBYYL0179	←	O
	26	FAN MOTOR BRACKET	2	CWD541265	←	
	27	SCREW - FAN MOTOR BRACKET	2	CWH551049J	←	
	28	AIR GUIDER B.W.	2	ACXD32-01510	←	
	29	AIR GUIDER B.W.	2	ACXD32-01520	←	
	30	DRAIN PAN - COMPLETE	1	CWH40C1134	←	
	31	CONTROL BOARD A'SSY	1	CWH10K1262	←	
⚠	32	ELECTRONIC CONTROLLER - (MAIN)	1	ACXA74C27460	ACXA74C27470	O
⚠	33	TERMINAL BOARD ASS'Y	1	CWA28K1161	←	O
⚠	35	TRANSFORMER - COMPLETE	1	CWA40C1106	←	O
	36	CONTROL BOARD COVER	1	ACXH13C07160	←	
	37	CABINET BOTTOM PLATE - COMPLETE	1	CWE05C1014	←	
	38	CABINET TOP PLATE	1	CWE031215	←	
	39	AIR FILTER	1	CWD001390	←	
	40	ACCESSORY - COMPLETE (FLEXIBLE PIPE & FOAM)	1	CWH82C2111	←	
⚠	41	WIRED REMOTE CONTROL COMPLETE	1	ACXA75C28720	←	O
⚠	42	REMOTE CONTROL CABLE	1	ACXA22-00890	←	O
	43	OPERATING INSTRUCTION	1	ACXF55-35351	←	
	44	OPERATING INSTRUCTION	1	ACXF55-35361	←	
	45	OPERATING INSTRUCTION	1	ACXF55-35371	←	
	46	INSTALLATION INSTRUCTION	1	ACXF60-60091	←	
	47	INSTALLATION INSTRUCTION	1	ACXF60-60100	←	
	48	INSTALLATION INSTRUCTION	1	ACXF60-60110	←	
	49	INSTALLATION INSTRUCTION	1	ACXF60-60120	←	

SAFETY	REF NO.	PART NAME & DESCRIPTION	QTY.	CS-Z25CD3EAW	CS-Z35CD3EAW	REMARK
	50	INSTALLATION INSTRUCTION	1	ACXF60-60130	←	
	51	INSTALLATION INSTRUCTION	1	ACXF60-60140	←	
	52	INSTALLATION INSTRUCTION	1	ACXF60-60150	←	
	53	INSTALLATION INSTRUCTION	1	ACXF60-60160	←	
	54	INSTALLATION INSTRUCTION	1	ACXF60-60170	←	
	55	INSTALLATION INSTRUCTION	1	ACXF60-60180	←	
	56	INSTALLATION INSTRUCTION	1	ACXF60-60190	←	
	57	INSTALLATION INSTRUCTION	1	ACXF60-60200	←	
	58	INSTALLATION INSTRUCTION	1	ACXF60-60210	←	
	59	INSTALLATION INSTRUCTION	1	ACXF60-60220	←	
	60	INSTALLATION INSTRUCTION	1	ACXF60-60230	←	
	61	INSTALLATION INSTRUCTION	1	ACXF60-60240	←	
	62	INSTALLATION INSTRUCTION	1	ACXF60-60250	←	
	63	INSTALLATION INSTRUCTION	1	ACXF60-60260	←	
	64	INSTALLATION INSTRUCTION	1	ACXF60-60270	←	
	65	INSTALLATION INSTRUCTION	1	ACXF60-60280	←	
	66	INSTALLATION INSTRUCTION	1	ACXF60-60290	←	
	67	INSTALLATION INSTRUCTION	1	ACXF60-60300	←	
	68	BASE BOARD - COMPLETE	1	ACXG62C02511	←	
	69	SHOCK ABSORBER (LEFT)	1	ACXG70-08900	←	
	70	SHOCK ABSORBER (RIGHT)	1	ACXG70-08910	←	
	71	C. C. CASE	1	ACXG50-52123	←	
	72	MODEL LABEL	2	ACXF87-53310	ACXF87-53320	
	73	BAG	1	ACXG86-05811	←	
	74	PARTICULAR PIECE	1	CWD934076	←	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- “O” marked parts are recommended to be kept in stock.

SAFETY	REF NO.	PART NAME & DESCRIPTION	QTY.	CS-Z50CD3EAW	CS-Z60CD3EAW	REMARK
	1	CABINET TOP PLATE - COMPLETE	1	CWE03C1169	←	
	2	FOAMED STYRENE COMPLETE	1	CWG07C1094	←	
	3	FOAMED STYRENE COMPLETE	1	CWG07C1089	←	
	4	FOAMED STYRENE COMPLETE	1	CWG07C1090	←	
	5	BULKHEAD	1	CWD531059	←	
	6	CABINET SIDE PLATE - COMPLETE	1	CWE04C1565	←	
	7	CABINET SIDE PLATE - COMPLETE	1	ACXE04C07290	←	
	8	PARTICULAR PLATE	4	CWD912571	←	
	9	FAN MOTOR BRACKET	1	CWD541246	←	
	10	SCREW - FAN MOTOR BRACKET	6	CWH55406J	←	
⚠	11	PUMP - COMPLETE	1	ACXB53C00550	←	O
	12	ANTI - VIBRATION BUSHING	3	CWH501131	←	
⚠	13	FLOAT SWITCH COMPLETE	1	CWA12C1034	←	O
	14	DRAIN NOZZLE	1	CWH411027	←	
	15	FLEXIBLE PIPE - COMPLETE	1	CWH85C1120	←	
	16	PLATE SPRING	1	CWH711022	←	
	17	WIRE SPRING	1	CWH722018	←	
	18	PARTICULAR PIECE - COMPLETE	1	CWD93C1191	←	
	19	EVAPORATER - COMPLETE	1	ACXB30C10370	←	O
	20	FLARE NUT (1/4")	1	CWT251030	←	
	21	FLARE NUT (1/2")	1	CWT251032	←	
	22	HOLDER - SENSOR	2	CWH32143	←	
⚠	23	SENSOR COMPLETE	1	ACXA50C00030	←	O
	24	BLOWER WHEEL ASS'Y	2	ACXH01K00510	←	
⚠	25	FAN MOTOR	1	L6CBYYL0179	←	O
	26	FAN MOTOR BRACKET	2	CWD541265	←	
	27	SCREW - FAN MOTOR BRACKET	2	CWH551049J	←	
	28	AIR GUIDER B.W.	2	ACXD32-01510	←	
	29	AIR GUIDER B.W.	2	ACXD32-01520	←	
	30	DRAIN PAN - COMPLETE	1	CWH40C1134	←	
	31	CONTROL BOARD A'SSY	1	CWH10K1262	←	
⚠	32	ELECTRONIC CONTROLLER - (MAIN)	1	ACXA74C27480	ACXA74C27490	O
⚠	33	TERMINAL BOARD ASS'Y	1	CWA28K1161	←	O
⚠	35	TRANSFORMER - COMPLETE	1	CWA40C1106	←	O
	36	CONTROL BOARD COVER	1	ACXH13C07160	←	
	37	CABINET BOTTOM PLATE - COMPLETE	1	CWE05C1014	←	
	38	CABINET TOP PLATE	1	CWE031215	←	
	39	AIR FILTER	1	CWD001390	←	
⚠	40	ACCESSORY - COMPLETE (FLEXIBLE PIPE & FOAM)	1	CWH82C2111	←	
⚠	41	WIRED REMOTE CONTROL COMPLETE	1	ACXA75C28720	←	O
	42	REMOTE CONTROL CABLE	1	ACXA22-00890	←	O
	43	OPERATING INSTRUCTION	1	ACXF55-35351	←	
	44	OPERATING INSTRUCTION	1	ACXF55-35361	←	
	45	OPERATING INSTRUCTION	1	ACXF55-35371	←	
	46	INSTALLATION INSTRUCTION	1	ACXF60-60091	←	
	47	INSTALLATION INSTRUCTION	1	ACXF60-60100	←	
	48	INSTALLATION INSTRUCTION	1	ACXF60-60110	←	
	49	INSTALLATION INSTRUCTION	1	ACXF60-60120	←	


SAFETY	REF NO.	PART NAME & DESCRIPTION	QTY.	CS-Z50CD3EAW	CS-Z60CD3EAW	REMARK
	50	INSTALLATION INSTRUCTION	1	ACXF60-60130	←	
	51	INSTALLATION INSTRUCTION	1	ACXF60-60140	←	
	52	INSTALLATION INSTRUCTION	1	ACXF60-60150	←	
	53	INSTALLATION INSTRUCTION	1	ACXF60-60160	←	
	54	INSTALLATION INSTRUCTION	1	ACXF60-60170	←	
	55	INSTALLATION INSTRUCTION	1	ACXF60-60180	←	
	56	INSTALLATION INSTRUCTION	1	ACXF60-60190	←	
	57	INSTALLATION INSTRUCTION	1	ACXF60-60200	←	
	58	INSTALLATION INSTRUCTION	1	ACXF60-60210	←	
	59	INSTALLATION INSTRUCTION	1	ACXF60-60220	←	
	60	INSTALLATION INSTRUCTION	1	ACXF60-60230	←	
	61	INSTALLATION INSTRUCTION	1	ACXF60-60240	←	
	62	INSTALLATION INSTRUCTION	1	ACXF60-60250	←	
	63	INSTALLATION INSTRUCTION	1	ACXF60-60260	←	
	64	INSTALLATION INSTRUCTION	1	ACXF60-60270	←	
	65	INSTALLATION INSTRUCTION	1	ACXF60-60280	←	
	66	INSTALLATION INSTRUCTION	1	ACXF60-60290	←	
	67	INSTALLATION INSTRUCTION	1	ACXF60-60300	←	
	68	BASE BOARD - COMPLETE	1	ACXG62C02511	←	
	69	SHOCK ABSORBER (LEFT)	1	ACXG70-08900	←	
	70	SHOCK ABSORBER (RIGHT)	1	ACXG70-08910	←	
	71	C. C. CASE	1	ACXG50-52123	←	
	72	MODEL LABEL	2	ACXF87-53330	ACXF87-53340	
	73	BAG	1	ACXG86-05811	←	
	74	PARTICULAR PIECE	1	CWD934076	←	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- “O” marked parts are recommended to be kept in stock.

22.2 Outdoor Unit

22.2.1 CU-Z25CBEA



Note

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.


SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-Z25CBEA	REMARK
	1	CHASSIS COMPLETE	1	CWD52K1399	
	2	FAN MOTOR BRACKET	1	CWD541157	
	3	SCREW - FAN MOTOR BRACKET	2	ACXH55-07140	
	4	FAN MOTOR	1	L6CAYYYL0064	O
	5	SCREW - FAN MOTOR MOUNT	4	CWH55252J	
	6	PROPELLER FAN ASSY	1	CWH03K1100	
	7	NUT - PROPELLER FAN	1	CWH56053J	
	8	COMPRESSOR	1	9RS102XFA21	O
	9	ANTI - VIBRATION BUSHING	3	CWH50077	
	10	NUT - COMPRESSOR MOUNT	3	CWH561096	
	11	CONDENSER	1	ACXB32C00760	
	12	HOLDER COUPLING	1	CWH351233	
	13	4-WAYS VALVE	1	ACXB00-01290	O
	14	DISCHARGE MUFFLER (4-WAYS VALVE)	1	CWB121010	
	15	2-WAYS VALVE (LIQUID)	1	ACXB02-02650	O
	16	3-WAY VALVE (GAS)	1	CWB011374	O
	17	TERMINAL COVER	1	CWH171039A	
	18	NUT - TERMINAL COVER	1	CWH7080300J	
	19	SOUND PROOF BOARD	1	CWH151428	
	20	SOUND PROOF MATERIAL (COMP. TOP)	1	CWG302314	
	21	SOUND PROOF MATERIAL (COMP. BODY)	1	CWG302948	
	22	SOUND PROOF MATERIAL (OVERLAP)	1	CWG302316	
	23	SOUND PROOF MATERIAL (CABINET SIDE PLATE)	1	CWG302994	
	24	SENSOR CO - COMP TEMP	1	CWA50C2632	O
	25	CONTROL BOARD COVER - TOP	1	ACXH13-00450	
	26	ELECTRONIC CONTROLLER - MAIN	1	ACXA74C25220R	O
	27	TERMINAL BOARD ASSY	1	CWA28K1110J	O
	28	CABINET SIDE PLATE CO.	1	ACXE04C00460	
	29	SENSOR CO - AIR TEMP AND PIPE TEMP	1	CWA50C3079	O
	30	CABINET SIDE PLATE	1	CWE041858A	
	31	CABINET FRONT PLATE CO.	1	CWE06C1566	
	32	DISCHARGE GRILLE	1	CWE201306	
	33	CABINET TOP PLATE	1	CWE031230A	
	34	PLATE - C. B. COVER TERMINAL	1	CWH131301	
	35	CONTROL BOARD COVER CO.	1	CWH13C1359	
	36	STRAINER	1	CWB111032	
	37	REACTOR	1	G0C392J00028	O
	38	EXPANSION VALVE	1	ACXB05-01100	
	39	V-COIL COMPLETE (4-WAY VALVE)	1	ACXA43C00250	O
	40	V-COIL COMPLETE (EXPANSION VALVE)	1	ACXA43C07230	O

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-Z25CBEA	REMARK
	41	RECEIVER	1	CWB14011	
	42	WIRE NET	1	ACXD04-00040A	
	43	BAG - COMPLETE	1	ACXH82C21741	
	44	PANASONIC BADGE	1	CWE373439	
	45	INSTALLATION INSTRUCTION	1	ACXF60-60320	
	46	INSTALLATION INSTRUCTION	1	ACXF60-60330	
	47	INSTALLATION INSTRUCTION	1	ACXF60-60340	
	48	INSTALLATION INSTRUCTION	1	ACXF60-60350	
	49	INSTALLATION INSTRUCTION	1	ACXF60-60360	
	50	INSTALLATION INSTRUCTION	1	ACXF60-60370	
	51	INSTALLATION INSTRUCTION	1	ACXF60-60380	
	52	INSTALLATION INSTRUCTION	1	ACXF60-60390	
	53	INSTALLATION INSTRUCTION	1	ACXF60-60400	
	54	INSTALLATION INSTRUCTION	1	ACXF60-60410	
	55	INSTALLATION INSTRUCTION	1	ACXF60-60420	
	56	INSTALLATION INSTRUCTION	1	ACXF60-60430	
	57	INSTALLATION INSTRUCTION	1	ACXF60-60440	
	58	INSTALLATION INSTRUCTION	1	ACXF60-60450	
	59	INSTALLATION INSTRUCTION	1	ACXF60-60460	
	60	INSTALLATION INSTRUCTION	1	ACXF60-60470	
	61	INSTALLATION INSTRUCTION	1	ACXF60-60480	
	62	INSTALLATION INSTRUCTION	1	ACXF60-60490	
	63	INSTALLATION INSTRUCTION	1	ACXF60-60500	
	64	INSTALLATION INSTRUCTION	1	ACXF60-60510	
	65	INSTALLATION INSTRUCTION	1	ACXF60-60520	
	66	INSTALLATION INSTRUCTION	1	ACXF60-60530	
	67	BAG	1	ACXG86-02390	
	68	BASE BOARD - COMPLETE	1	ACXG62C01320	
	69	SHOCK ABSORBER (TOP RIGHT)	1	ACXG70-08880	
	70	SHOCK ABSORBER (TOP LEFT)	1	ACXG70-08890	
	71	C.C. CASE	1	ACXG50-48865	
	72	MODEL LABEL	2	ACXF87-53640	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

22.2.2 CU-Z35CBEA



Note

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.


SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-Z35CBEA	REMARK
	1	CHASSIS COMPLETE	1	CWD52K1277	
	2	FAN MOTOR BRACKET	1	CWD541167	
	3	SCREW - FAN MOTOR BRACKET	2	ACXH55-07140	
	4	FAN MOTOR	1	L6CAYYYL0064	O
	5	SCREW - FAN MOTOR MOUNT	4	CWH55252J	
	6	PROPELLER FAN ASSY	1	CWH03K1066	
	7	NUT - PROPELLER FAN	1	CWH56053J	
	8	COMPRESSOR	1	9RS102XFA21	O
	9	ANTI - VIBRATION BUSHING	3	CWH50077	
	10	NUT - COMPRESSOR MOUNT	3	CWH561096	
	11	CONDENSER	1	ACXB32C12500	
	12	HOLDER COUPLING	1	CWH351233	
	13	4-WAYS VALVE	1	ACXB00-01290	O
	14	DISCHARGE MUFFLER (4-WAYS VALVE)	1	CWB121010	
	15	2-WAYS VALVE (LIQUID)	1	ACXB02-02650	O
	16	3-WAY VALVE (GAS)	1	CWB011374	O
	17	TERMINAL COVER	1	CWH171039A	
	18	NUT - TERMINAL COVER	1	CWH7080300J	
	19	SOUND PROOF BOARD	1	ACXH15-01590	
	20	SOUND PROOF MATERIAL (OVERLAP)	1	CWG302701	
	21	SOUND PROOF MATERIAL (COMP. BODY)	1	ACXG30-08490	
	22	SOUND PROOF MATERIAL (COMP. TOP)	1	CWG302719	
	23	SENSOR CO - COMP TEMP	1	CWA50C2894	O
	24	CONTROL BOARD COVER - TOP	1	CWH131473	
	25	ELECTRONIC CONTROLLER - MAIN	1	ACXA74C25230R	O
	26	TERMINAL BOARD ASSY	1	CWA28K1110J	O
	27	CABINET SIDE PLATE CO.	1	ACXE04C05220	
	28	SENSOR CO - AIR TEMP AND PIPE TEMP	1	CWA50C3078	O
	29	CABINET SIDE PLATE	1	ACXE04-13050A	
	30	CABINET FRONT PLATE CO.	1	ACXE06C02890	
	31	DISCHARGE GRILLE	1	CWE201285	
	32	CABINET TOP PLATE	1	ACXE03-04830A	
	33	PLATE - C. B. COVER TERMINAL	1	CWH131470	
	34	CONTROL BOARD COVER CO.	1	ACXH13C02860	
	35	STRAINER	1	CWB111032	
	36	REACTOR	1	G0C392J00028	O
	37	EXPANSION VALVE	1	ACXB05-01100	
	38	V-COIL COMPLETE (4-WAY VALVE)	1	ACXA43C00250	O
	39	V-COIL COMPLETE (EXPANSION VALVE)	1	ACXA43C07230	O
	40	RECEIVER	1	CWB14011	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-Z35CBEA	REMARK
	41	WIRE NET	1	CWD041200A	
	42	BAG - COMPLETE	1	ACXH82C21741	
	43	PANASONIC BADGE	1	CWE373439	
	44	INSTALLATION INSTRUCTION	1	ACXF60-60320	
	45	INSTALLATION INSTRUCTION	1	ACXF60-60330	
	46	INSTALLATION INSTRUCTION	1	ACXF60-60340	
	47	INSTALLATION INSTRUCTION	1	ACXF60-60350	
	48	INSTALLATION INSTRUCTION	1	ACXF60-60360	
	49	INSTALLATION INSTRUCTION	1	ACXF60-60370	
	50	INSTALLATION INSTRUCTION	1	ACXF60-60380	
	51	INSTALLATION INSTRUCTION	1	ACXF60-60390	
	52	INSTALLATION INSTRUCTION	1	ACXF60-60400	
	53	INSTALLATION INSTRUCTION	1	ACXF60-60410	
	54	INSTALLATION INSTRUCTION	1	ACXF60-60420	
	55	INSTALLATION INSTRUCTION	1	ACXF60-60430	
	56	INSTALLATION INSTRUCTION	1	ACXF60-60440	
	57	INSTALLATION INSTRUCTION	1	ACXF60-60450	
	58	INSTALLATION INSTRUCTION	1	ACXF60-60460	
	59	INSTALLATION INSTRUCTION	1	ACXF60-60470	
	60	INSTALLATION INSTRUCTION	1	ACXF60-60480	
	61	INSTALLATION INSTRUCTION	1	ACXF60-60490	
	62	INSTALLATION INSTRUCTION	1	ACXF60-60500	
	63	INSTALLATION INSTRUCTION	1	ACXF60-60510	
	64	INSTALLATION INSTRUCTION	1	ACXF60-60520	
	65	INSTALLATION INSTRUCTION	1	ACXF60-60530	
	66	BAG	1	ACXG86-03761	
	67	BASE BOARD - COMPLETE	1	ACXG62C01130	
	68	SHOCK ABSORBER (TOP RIGHT)	1	ACXG70-07960	
	69	SHOCK ABSORBER (TOP LEFT)	1	ACXG70-07970	
	70	C.C. CASE	1	ACXG50-48874	
	71	MODEL LABEL	2	ACXF87-53650	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

22.2.3 CU-Z50CBEA CU-Z60CBEA



Note

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-Z50CBEA	CU-Z60CBEA	REMARK
	1	CHASSIS COMPLETE	1	ACXD52K00320	←	
	2	FAN MOTOR BRACKET	1	ACXD54-00140	←	
	3	SCREW - FAN MOTOR BRACKET	2	ACXH55-07140	←	
	4	FAN MOTOR	1	L6CAYYYL0076	←	O
	5	SCREW - FAN MOTOR MOUNT	4	CWH551106J	←	
	6	PROPELLER FAN ASSY	1	ACXH03K00070	←	
	7	NUT - PROPELLER FAN	1	CWH56053J	←	
	8	COMPRESSOR	1	9RD132XAA21	←	O
	9	ANTI - VIBRATION BUSHING	3	CWH50077	←	
	10	NUT - COMPRESSOR MOUNT	3	CWH561096	←	
	11	CONDENSER	1	ACXB32C08610	←	
	12	HOLDER COUPLING	1	ACXH35-00080	←	
	13	4-WAYS VALVE	1	ACXB00-01320	←	O
	14	2-WAYS VALVE (LIQUID)	1	ACXB02-02560	←	O
	15	3-WAY VALVE (GAS)	1	ACXB01-03760	←	O
	16	TERMINAL COVER	1	CWH171039A	←	
	17	NUT - TERMINAL COVER	1	CWH7080300J	←	
	18	SOUND PROOF BOARD	1	ACXH15-00200	←	
	19	SOUND PROOF MATERIAL (COMP. BODY)	1	CWG302950	←	
	20	SOUND PROOF MATERIAL (COMP. TOP)	1	CWG302630	←	
	21	SOUND PROOF MATERIAL (CABINET SIDE PLATE)	1	CWG302632	←	
	22	SOUND PROOF MATERIAL (OVERLAP)	1	CWG302636	←	
	23	SENSOR CO - COMP TEMP	1	CWA50C2185	←	O
	24	CONTROL BOARD COVER - TOP	1	ACXH13-00490	←	
	25	ELECTRONIC CONTROLLER - MAIN	1	ACXA74C25240R	ACXA74C25250R	O
	26	TERMINAL BOARD ASSY	1	CWA28K1110J	←	O
	27	CABINET SIDE PLATE CO.	1	ACXE04C00690	←	
	28	SENSOR CO - AIR TEMP AND PIPE TEMP	1	CWA50C3079	←	O
	29	CABINET SIDE PLATE	1	ACXE04-00490A	←	
	30	CABINET FRONT PLATE CO.	1	ACXE06K00050	←	
	31	DISCHARGE GRILLE	1	ACXE20-00260	←	
	32	CABINET TOP PLATE	1	ACXE03-00170A	←	
	33	PLATE - C. B. COVER TERMINAL	1	CWH131470	←	
	34	CONTROL BOARD COVER CO.	1	ACXH13C00170	←	
	35	HANDLE	1	CWE161010	←	
	36	STRAINER	1	CWB11094	←	
	37	REACTOR	1	G0C392J00027	G0C392J00029	O
	38	EXPANSION VALVE	1	ACXB05-01100	←	
	39	V-COIL COMPLETE (4-WAY VALVE)	1	ACXA43C00250	←	O
	40	V-COIL COMPLETE (EXPANSION VALVE)	1	ACXA43C07230	←	O

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-Z50CBEA	CU-Z60CBEA	REMARK
	41	RECEIVER	1	CWB14011	←	
	42	WIRE NET	1	ACXD04-00130A	←	
	43	BAG - COMPLETE	1	ACXH82C21741	←	
	44	PANASONIC BADGE	1	CWE373439	←	
	45	INSTALLATION INSTRUCTION	1	ACXF60-60320	←	
	46	INSTALLATION INSTRUCTION	1	ACXF60-60330	←	
	47	INSTALLATION INSTRUCTION	1	ACXF60-60340	←	
	48	INSTALLATION INSTRUCTION	1	ACXF60-60350	←	
	49	INSTALLATION INSTRUCTION	1	ACXF60-60360	←	
	50	INSTALLATION INSTRUCTION	1	ACXF60-60370	←	
	51	INSTALLATION INSTRUCTION	1	ACXF60-60380	←	
	52	INSTALLATION INSTRUCTION	1	ACXF60-60390	←	
	53	INSTALLATION INSTRUCTION	1	ACXF60-60400	←	
	54	INSTALLATION INSTRUCTION	1	ACXF60-60410	←	
	55	INSTALLATION INSTRUCTION	1	ACXF60-60420	←	
	56	INSTALLATION INSTRUCTION	1	ACXF60-60430	←	
	57	INSTALLATION INSTRUCTION	1	ACXF60-60440	←	
	58	INSTALLATION INSTRUCTION	1	ACXF60-60450	←	
	59	INSTALLATION INSTRUCTION	1	ACXF60-60460	←	
	60	INSTALLATION INSTRUCTION	1	ACXF60-60470	←	
	61	INSTALLATION INSTRUCTION	1	ACXF60-60480	←	
	62	INSTALLATION INSTRUCTION	1	ACXF60-60490	←	
	63	INSTALLATION INSTRUCTION	1	ACXF60-60500	←	
	64	INSTALLATION INSTRUCTION	1	ACXF60-60510	←	
	65	INSTALLATION INSTRUCTION	1	ACXF60-60520	←	
	66	INSTALLATION INSTRUCTION	1	ACXF60-60530	←	
	67	BAG	1	ACXG86-02750	←	
	68	BASE BOARD - COMPLETE	1	ACXG62C01110	←	
	69	SHOCK ABSORBER (TOP LEFT)	1	ACXG70-07760	←	
	70	SHOCK ABSORBER (TOP RIGHT)	1	ACXG70-07770	←	
	71	C.C. CASE	1	ACXG50-48885	←	
	72	MODEL LABEL	2	ACXF87-53660	ACXF87-53670	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- “O” marked parts are recommended to be kept in stock.